


COMPACT PROTOCOL ANALYZER

LE-1500R

INSTRUCTION MANUAL



Instruction

Thank you for your purchase of LE-1500R.

To use it correctly, you are advised to read and understand this instruction manual thoroughly. Keep this together with the warranty. If you encounter any problems, you will find helpful information in this manual.



NOTICE

It is prohibited to reprint or duplicate any part of the whole of this instruction manual without prior permission from LINEEYE.

The content of this instruction manual and specifications of the products are subject to change without any notice.

This instruction manual has been designed and edited with great care to give you all necessary information. If you have any questions, feel free to direct your inquiries to LINEEYE.

LINEEYE makes no warranty or guarantee, either expressed or implied with respect to its quality, performance, merchantability, or fitness for a particular purpose. LINEEYE shall not be liable for direct, in-direct, special, incidental, or consequential damages resulting from any defect in the product. The warranty and remedies set forth above are exclusive and in lieu of all others.



USER LIMITATION

This product has not been developed for the use that needs exclusively high reliability and safety: aerospace apparatus, trunk communication apparatus, nuclear control apparatus, medical apparatus related with life maintenance etc. Therefore, do no use for those purposes.

LE-series models with Wi-Fi function (IEEE 802.11b/g/n) emit radio wave. Please do not use it near a medical device, microwave, high-level electronics, TV, radio, wireless station for mobile communication, or specified low power radio station. To use LE-series in the place where an administrator limits the use of radio devices, follow the instruction of the administrator.

The Wi-Fi module used for the LE-series conforms to SRRC(China), FCC (USA), CE (EU), TELEC (Japan), KCC (Korea), ISED (Canada), NCC (Republic of China), however, as its product (LE-series) the Wi-Fi function is available only in Japan, USA, Canada, and EU nations in compliance with RE directive (2014/53/EU).

To use the product other than above countries, order LE-series without Wi-Fi function. Please contact the sales department for more details.

=== Notice ===

This product contains a battery.

To keep the quality of the battery, LINEEYE does not fully charge the battery.

Before using the battery, please make sure to charge the battery. When you dispose of it, please follow the regulation of the region

Safety Information

Read this first !!

This Safety Information includes the following important information in order to not only have you learn the right way to use the analyzer, but also prevent you from causing damage to people and property. Before using, please read the main contents after you understand the following symbols & marks.

-  **Warning** Should the device be used without following these symbols, there is a possibility of accidents, such as a death or a serious injury, occurring.
-  **Caution** Should the device be used without following these symbols, there is a possibility of accidents, such as an injury ^{*1}, and material damage ^{*2} occurring.
- *1 "Injury" indicates injury, burn and electric shock, or the like which does not require hospitalization or the extended hospital visit.
- *2 "Material damage" indicates damage related to a house, a building, furniture, apparatus, livestock or a pet.



	 Warning
	<ul style="list-style-type: none"> ● Stop using the analyzer immediately when smoke or smells emanate from itself. Continuous use may result in an electric shock, a burn and/ or fire.
	<ul style="list-style-type: none"> ● Stop using the analyzer when a liquid or foreign substance get into the analyzer. This may result in an electric shock or fire. ➔ Immediately switch off the analyzer and unplug it.
	<ul style="list-style-type: none"> ● Do not disassemble, modify or repair analyzer. This may result in a injury, an electric shock, fire, explosion and/or a breakdown due to overheating.
	<ul style="list-style-type: none"> ● Do not put the analyzer in fire or place near the heater. This may result in a injury and fire due to overheating or explosion.
	<ul style="list-style-type: none"> ● Stop using the analyzer should a liquid or foreign substance get into the analyzer. This may result in an electric shock or fire.
	<ul style="list-style-type: none"> ● Never plug or unplug the AC adapter in wet hands.
	<ul style="list-style-type: none"> ● Do not subject the analyzer to extreme conditions.
	<ul style="list-style-type: none"> ● Do not use any AC adapter and battery other than those specified by LINEEYE. It can cause heat, fire, liquid spill, and malfunction.

⚠ Caution

	<ul style="list-style-type: none">•Do not leave the analyzer in the following conditions. Strong magnetic field, static electricity or dusty place. Temperature and humidity above the specification or where dew condensation appears. Not flat, or shaking place. Place with leaking water or electricity. Place affected by direct sun or near the fire .  Please do not leave the analyzer in the car during the summer.
	<ul style="list-style-type: none">•Do not use at the following situations. The radio wave by the analyzer may cause trouble. Near a medical device such as cardiac pacemaker or hearing aid Near an automatic controller such as fire-alarm box or automatic door Near a microwave, high-level electronics, TV, or radio. Near a wireless station for mobile communications or a specified low power radio station
	<p>Remove the battery from the analyzer, when you throw away.</p>

⚠ Caution

	<ul style="list-style-type: none">•Please follow the instruction for the AC adaptor. Do no use when it brakes. Do not damage the AC adaptor or cable. Do not place near the heater or put in the fire. Do not disassemble, modify the AC adaptor or cable. Do not curve the cable around the AC adaptor
	<p>Plug the AC adaptor correctly. Take off the dust from the AC adaptor. Unplug the AC adaptor when you are not using the analyzer. Unplug the AC adaptor correctly.</p>

CONTENTS

Instruction	1
Safety Information.....	2
Chapter 1 Before Using the Product.....	6
1.1 Guide to This Manual.....	6
1.2 Unpacking	6
1.3 Major Functions and Features.....	7
1.4 Panel Information.....	8
1.5 Power Supply and Battery.....	11
Chapter 2 Basic Operation and Set-Up	12
2.1 Power Source ON/OFF.....	12
2.2 Set the Measurement Port (INTERFACE SETUP).....	13
2.3 Connect to the Target Devices.....	14
Connect to RS-232C	14
Connect to RS-422 or RS-485.....	15
Connect to TTL	16
2.4 Characters Input.....	17
2.5 Environmental Setting (Conditions).....	18
BUFFER SELECT.....	18
RECORD&DISPLAY CONTROL(Record and Display Setting).....	19
PRINT OUT CONDITION	20
REMOTE CONDITION (Remote communication condition setting)	20
AUTO RUN (Automatic Start and Stop).....	21
TIME & DATE SET	21
OTHER FUNCTION.....	21
2.6 Communication Condition Setting (Configuration)	22
Communication Protocol Setting.....	22
Communication Condition Settings	22
Chapter 3 Monitor Function	25
3.1 Online Monitor Function (ONLINE)	25
3.2 Analog and Delay Time Function.....	26
Chapter 4 Simulation Function.....	27
4.1 Preparation for Simulating.....	28
Registration of Transmission Data (DATA TBL).....	28
Driver Control [RS-422/485] (DRVCTRL).....	31
Terminator for RS-422/485 Port.....	31
Controlling a Control Line (LINECTRL).....	32
4.2 MANUAL Mode.....	33
4.3 Flow Control Test(FLOW).....	34
4.4 Echo Back Test (ECHO)	36
Chapter 5 Bit Error Rate Test (BERT) Function.....	37
5.1 Start and End a Measurement	39
5.2 Data Use	39
Chapter 6 Useful Functions	40
6.1 Trigger Function (TRIGGER)	40
Trigger Output.....	40
Trigger Factor.....	41
Trigger Action	42
6.2 Timer/Counter Function(TM/CT).....	43
6.3 Timing Waveform Measurement Function(WAVE MON).....	44
6.4 Communication Condition Auto Setting Function(AUTO CONF)	46
6.5 Logging Function for a Long Time	47
6.6 Automatic Start and Stop Function(AUTO RUN).....	48

6.7 Display Screen Switching Function	48
Display Switch	48
Display Code Change	48
Scroll	48
Jump	48
6.8 Translation Function	49
6.9 Retrieval Function.....	51
6.10 Recording Function to Measure Additional Information (Idle Time, Time Stamp etc.).....	52
Idle Time Display Function	52
Time Stamp Function.....	53
Line State Display Function	53
Chapter 7 Data Usage Chapter	54
7.1 Hard Copy Printing	55
7.2 Normal Printing	55
Printing Format For The Measured Data	55
Printing Example of Data	56
Other printing.....	57
7.3 Usage on PC.....	58
Chapter 8 Save and Load Data	59
8.1 Storage Device	59
8.2 File Management Function	59
Save	60
Filter	60
Load.....	60
Delete.....	61
Chapter 9 Documents	62
9.1 Calculation of Block Check.....	62
9.2 Frame.....	63
9.3 Data Code Table	63
9.4 Specifications of Translation Display	68
BSC Translation Display	68
PPP Translation Display	69
Chapter 10 Specifications and Maintenance	71
10.1 Specifications of Function and Hardware.....	71
10.2 Ports.....	73
RS-422/485 port	73
TTL Port	73
RS-232C (V.24) port	74
External Input/Output Terminal.....	74
AUX(RS-232C) Port.....	75
USB Device port	75
USB Host port.....	75
USB Driver Installation.....	76
10.3 Soft Reset.....	77
10.4 Using the Latest Function	77
10.5 Troubleshooting.....	78
10.6 Warranty and After service	79
Warranty.....	79
User Registration	79
Repair	79
After Support	79

Chapter 1 Before Using the Product

1.1 Guide to This Manual

Descriptions in this manual assume the following:

Screen Display Representation

- Printed representation of screen displays in this manual may not be the same as that actually displayed concerning the font and special symbols.
- Descriptions of parts of the screen being displayed are enclosed in double quotation marks “ ”
- Flashing of the cursor or the like is not represented in this manual.

Representation of the Operating Procedure

- Represent keys in []
eg. Press  key. →Press [MENU].
- Successive key operations may be represented by putting their symbols one after another.
eg. Press [MENU], then press [0] to make a selection →Press [MENU],[0]to make a selection.
- Pressing two keys at the same time is represented by combining their symbols with “+.”
e.g. Press [SHIFT] and [PRINT] at the same time →Press [SHIFT]+[PRINT] to make a selection.

1.2 Unpacking

When you unpack the product, make sure of the following:

- The product has not been damaged during transit.
- You have received all the standard accessories listed below.
 - Protocol Analyzer 1
 - Interface Sub-board (attached to the analyzer) 1
 - Wide input AC Adapter (Model : 6A-181WP09) 1
 - DSUB25pin Monitor cable (Model : LE-25M1) 1
 - USB Cable 1
 - Utility CD 1
 - Carrying bag (Model : LEB-01) 1
 - Quick Start Guide 1
 - Registration card, Warranty 1
-  The card packed with the product is the user registration card for Japanese customers. For overseas customers, there is a user registration page on our web site.(<https://www.lineeye.com>)

Please let us know if you find any damage to the product caused by transportation, or if there are accessories lacking.

- Utility CD
This CD contains the following:
 - Manual folder : Instruction manuals for analyzer and options.
 - Utility folder : PC link software (light edition), Utility software, and a software to transfer the firmware
 - Driver folder : USB driver for analyzer to connect with PC.

1.3 Major Functions and Features

LE Series are handheld communication protocol analyzers. They are powerful tools for the development and inspection of communication systems devices, and for the diagnosis of communication networks.

Functions

This product has interfaces for RS-232C (V.24), RS-422/485, and TTL.

◆ On-line Monitoring

Monitors communication protocol or the transmission data on-line to check for existence of hindrance in the line or to analyze the communication.

◆ Simulating

Executes operating transmission of data as communication partner for tested devices/equipment.

◆ Bit Error Rate Test

Evaluates the quality of the data communication channel, including modems.

Features

- An arbitrary speed can be set. (Up to 500Kbps)
- The monitor/analysis capabilities supports real time display.
- AUTO SAVE function which can record measured data into SD card or USB flash memory for a long time.
- Useful timing waveform measurement function at the time of timing trouble regarding bit unit
- Battery-powered for 6.5 to 8 hours, light-weight (Approx. 800g), and compact design for field application
- Remote control by Wi-Fi (The Wi-Fi function is available only in Japan, USA, Canada, and EU nations where the product is needed to be compliant with RE directive (2014/53/EU).)

Optional Accessories

■ Interface Sub-Board B

By exchanging an interface sub-board for an option, it supports the current loop communication.

- OP-SB1C Expansion kit for current loop

■ Cable

- LE-259M1 DSUB 9pin Monitor cable

■ SDHC Card

It can be used for saving measured data and set-up conditions and for continuously recording for a long time.

- SD-16GX 16GB SD card
- SD-8GX 8GB SD card

■ Compact Thermal Printer

- DPU-414-PA Handy thermal printer for on-site printout of measurements


■ Software

The Windows software enables the analyzer to cooperate with a PC on measuring.


- LE-PC300R PC link software(for Windows)

1.4 Panel Information

General



Name		Function
①	AC Adapter Plug	Connects the AC adapter.(It deals with the polarity of plus and negative.)
②	Power Switch	Turns the power on/off.
③	SD Card Slot	The inlet for a SD card
④	USB Host Port	To connect to a USB flash memory
⑤	Interface Sub-Board	A sub-board equipped with RS-232C, RS-422/485, and TTL interface
⑥	RS-232C Port	Measurement port for RS-232C (V.24)
⑦	TTL/ External Signal I/O terminal	Measurement port for TTL. A port for external signal I/O
⑧	RS-422/485 Port	Measurement port for RS-422/485
⑨	AUX(RS-232C) Port	Used to input or output external equipment equipped with RS-232C interface.
⑩	USB Device Port	Uses for a remote-control from a PC, or for updating firmware.
⑪	Liquid Crystal Display	Wide view angle and high contrast liquid crystal display.
⑫	Line State LED	Indicates logical status of signal line on the target interface.
⑬	Action State LED	Indicates the status of an analyzer's operation.
⑭	Keypad	Press to enter commands and data.
⑮	Battery Cover	Open only when replacing the nickel-hydrogen battery.
⑯	Contrast Adjust Knob	Adjusts the display contrast.



Key	Function
[RUN]	Starts monitoring, measuring or testing operation.
[STOP]	Stops monitoring, measuring or testing operation. Interrupts printing.
[MENU]	Returns to the top menu for selecting functions and setting conditions. *Returns to the previous screen.
[DISPLAY MODE]	Displays the monitored or measured data. Switches over to the display format.
[TIME/COUNT]	Switches to counter/timer display and timing waveform display.
[LOAD/SAVE]	Sets configuration of file management for the storage device.
[FIND]	Switches over to the retrieval function.
[PRINT]	Switches over to the printing function.
[HEX/CHAR]	Switches over the monitored data displayed in char. to one in hexadecimal.
[ZOOM/CODE]	Zooms up in the timing waveform screen. Changes the display code of monitored data.
[PAGE UP]	Goes to previous data. Moves the setting items upward.
[PAGE DOWN]	Goes to next data. Moves the setting items downward.
[▲], [▼]	Scrolls the data line. Moves the cursor on the condition setting screen.
[◀], [▶]	Scrolls the displayed data character by character. Changes or selects the setting item on the condition setting screen.
[ENTER]	Definite input for execution of function or a command. Pauses the display when pressing the key during the measurement.
[0]~[F]	Enters the corresponding numerical values. Selects an item number or the data to be sent.
[TOP/DEL]	Displays the top section of data. Deletes the entry indicated by the cursor.
[END/X]	Jumps to the end of the screen. Enters data "Don't Care."
[SHIFT]	Press to use the expanded alternate function of each key.
[SHIFT] + [PRINT]	Prints a hard copy (screen image).
[SHIFT] + [FIND]	Sets configuration of retrieval condition.
[SHIFT] + [PAGE UP]	Moves to the setting help screen upward.
[SHIFT] + [PAGE DOWN]	Moves to the setting help screen downward.
[SHIFT] + [0]~[D]	Selects the fixed transmission data.
[SHIFT] + [E], ([F])	Turns the control line RS[CS](ER [CD]) on/off.
[SHIFT] + [▲], [▼]	Switches BUF 1 or BUF 2 when a buffer memory is divided into two parts. Switches signals on the timing observation screen.
[SHIFT] + [◀], [▶]	Displays the monitored data in bit shift. Moves a cursor on the timing observation screen.
[SHIFT] + [ZOOM/CODE]	Zooms down on the timing observation screen. Change the code in the opposite order of "CODE".
[SHIFT] + [DISPLAY MODE]	Turns on/off the back light of LCD.
[SHIFT] + [HEX/CHAR]	Switches a character input mode.
[ENTER] + [TOP/DEL]	Initializes to the factory setting by pressing it at the time of turning on the power.
[1] + [D]	Starts the diagnostics test if pressing these keys when turning on the power.

■ LCD Display

The LCD displays the measurement conditions, the monitored data and the measured results. The following information is displayed on the bottom line on the opening screen and the monitor data screen, corresponding to the caption printed below the LCD.

Printed Caption	Display	Meaning of Caption
Card	<Space>	A memory card is not inserted.
		A memory card is inserted.
		Unacceptable memory card is inserted.
Buf1/Buf2		A buffer memory is not divided.
		A buffer memory is divided into two parts, with the former half (BUF1) is in use.
		A buffer memory is divided into two parts, with the latter half (BUF2) is in use.
Position	Number	Displays data position on the upper left of the display screen.
Condition/Function	Message	Displays the transmission speed and display code. Displays the call status of each function.

■ Line State Indicator LEDs

These LEDs indicate the logical status (voltage level) of the INPUT/OUTPUT data on the signal lines connected to the measurement port in real time. There are two groups: DTE drive signal and DCE drive signal.

- A signal name and pin number correspond to the RS-232C port.
- The correspondences between signals and LEDs are shown in the following table:

Voltage Level on the Signal Lines			Two-Color LED	
RS-232C	RS-422/485	TTL	Red	Green
+3V≤VM	VA-VB>+0.2V	VT<VIL	Light on	Light off
-3V<VM<+3V	VA-VB<+0.05V	VIH<VT	Light off	Light off
VM<-3V			Light off	Light on

DTE	DCE
SD (2)	(3) RD
RS (4)	(5) CS
ER (20)	(6) DR
ST1 (24)	(8) CD
	(22) CI
	(15) ST2
	(17) RT

VM : Voltage Level of RS-232C

VT: TTL Level


V A : Voltage Level on the RS-422/RS-485 [-Terminal] VIH: Minimum of the threshold of input level H

V B : Voltage Level on the RS-422/RS-485 [+Terminal] VIL: Maximum of the threshold of input level L

■ Action State Indicator LEDs

These LEDs indicate the operating status by turning on/off a light of the analyzers.

LED	Status
RS-232C	RS-232C port is available.
Others	Ports but RS-232C (e.g. RS-422/485) are available.
SIM_DTE	Analyzers serve as DTE. The simulation and the bit error test functions are available.
SIM_DCE	Analyzers serve as DCE. The simulation and the bit error test functions are available.
MONITOR	The monitor functions are available.
RUN	The monitor, the measurement or the test function is running.
BT	<ul style="list-style-type: none"> • Red lighting : Battery Warning (Batteries are almost dead.) • Green blink : Recharging batteries • Green lighting : The charge is completed • Green high-speed blink : The charge is error (indicates the battery deterioration and disconnection)




1.5 Power Supply and Battery

This analyzer can perform AC power operation by attached AC adapter and battery drive by built-in rechargeable battery. The measurement setting is backed up by the battery even if the power supply is OFF. (However measured data will be erased when power supply is OFF.)

Attached AC Adapter

Wide range input AC adapter is attached.

- Input : 90V AC to 264V AC (Rating 100V AC to 240V AC), 50/60Hz
- Output : 9V DC \pm 5%, 2.0A max, Center positive
- Safety :PSE, UL, CUL, CCC, CE



Recharging the Battery

The Nickel-Hydrogen battery is built in and can perform the battery drive of about 6.5 to 8 hours when fully charge.

1. Plug the attached AC adapter into an AC power outlet.
2. The battery is recharged by connecting the plug of AC adapter into the AC adapter jack of analyzers, and BT LED will blink in green slowly.
3. The charge is completed when BT LED lights in green.

- ▢ The battery will be fully recharged in about 2.5 hours when the power switch is OFF. When the power switch is ON, the time for the charge will be a bit longer.
- ▢ BT LED will light in red when the battery is running short.
- ▢ When the LED repeats high-speed blink, indicates that the charge cannot be performed. It might be the battery deterioration and disconnection. Exchange to the new battery.
- ▢ Please recharge when the temperature is within the range of 5 °C to 40 °C. The charge is not started at any temperature other than this range.
- ▢ Be sure to use the AC adapter provided with this analyzer.

Replacement of Battery

■ Nickel-Hydrogen Battery



In a usual state of use, about 300 times charge and electric discharge use is possible, but if the battery can no longer drive your analyzer, or the service time after charging becomes extremely short, the battery must be replaced with a new one. (When you replace the batteries, turn OFF the power.)

1. Remove the battery cover from the bottom of your analyzer.
Disconnect the connector of the lead line on the battery and remove the battery.
2. Connect a new battery to the connector and set it in the battery holder. Put back the battery cover and tighten screws with great care so that the lead line is not pinched.

- If you are not going to use the analyzer for a long term, fill up the battery before finishing it.
After that, try to charge the battery every 6 month.
- A replacement Nickel-Hydrogen battery is to be ordered from the dealer who supplied your analyzer.
- New orders for batteries have to be paid even if it is still during warranty period because batteries are considered consumable parts.

 Attention
Embed securely the lead wire of the battery in the tying bunding band of the attachment in the time of the mounting of nickel hydrogen battery. The lead wire is damaged and is short-circuited, when lead wire is located between lid and main body in the screw stop, and it becomes trouble and cause of the accident. Be careful not to let the lead wire insert in there.

Install the base of the lead wire in the direction on the level.



■ Lithium Battery

The data of memory IC and timer IC is backed up for about 5 years by built-in Lithium battery even if the power supply is OFF. Every time the message “INITIALIZED!” is displayed on the opening screen of after turning on the power, it is time to replace the lithium battery.

- ▢ Exchanging Lithium batteries is done as exchange work in the factory.

Chapter 2 Basic Operation and Set-Up

2.1 Power Source ON/OFF

Power Source ON

Turn on the power of analyzer (Press left side button.)
The opening screen will be displayed after the self-check test.



- If "SELF CHECK NG" is displayed in the opening screen, please contact LINEEYE distributors or LINEEYE directly.
 - If <Firmware loader> is displayed, insert the appropriate sub-board and load the firmware to the analyzer.
- 10.4 Use the Latest Functions
- Use the AC adapter if BT LED lights on red.

Adjustment of the LCD display

If the contrast of the screen is too deep or too light, adjust it with the contrast adjust knob located on the right side of your analyzer.

- When no display is shown on the screen, it can be due to excessively light contrast. Try adjusting the contrast knob.

ON/OFF of Backlight

Press [SHIFT] + [DISPLAY MODE] to turn on/off the backlight.

- Using the backlight makes battery drive time shorter than when it is not used.

2.5 Environmental Setting (Conditions)

Selecting the Functions

Press [MENU] to display the top menu screen.




The "▶ ◀" mark tells you what function is selected.

Press [▲], [▼], [◀], or [▶] to move "▶ ◀" mark and select the function.


- The top menu screen will not be displayed while measuring (RUN LED is blinking).

Setting Change

"SETUP" menu is displayed on the right side of the top menu.



When you want to change the setting, press a SETUP number ([0] to [F]) on the top menu screen to display the setting screen. Depending on what you select (MONITOR etc), the setting screen may be different. For example "2:TRIGGER", "3:CONDITION" etc. are displayed in the left picture.



Move the cursor ("◀") by [▼], [▲], [PAGE DOWN], [PAGE UP] and select the setting ("SELECT") shown on the right side of the screen by pressing [◀], [▶] or [0] ~ [F] keys.

- When the selected items of "SELECT" have more than one page to display, press [SHIFT]+[PAGE DOWN]/[SHIFT]+[PAGE UP] to go to the previous/next page.

2.5 Environmental Setting (Conditions)

2.6 Communication Condition Setting (Configuration)

Connection to the Target Devices

Select the appropriate measurement port and connect the target device to the analyzer.

2.2 Set the Measurement Port (INTERFACE SETUP)

2.3 Connect to the Target Devices

Start and Stop Measurement

When [RUN] is pressed, RUN LED starts lightening and the selected measurement function begins. During the measurement, the analyzer saves data to the memory displaying the data on the screen in real time.

When [Stop] is pressed, RUN LED stops lightening and displays the last data measured. It is possible that measurement stops automatically under the specific conditions by the trigger function.

- When the capture buffer protection, automatic start/ stop function and logging function for a long time are set, the messages like "WRITE PROTECT," "AUTO RUN WAIT" and "AUTO SAVE FILE EXIST" will be displayed.

 2.5 Environmental Setting  6.1 Trigger Function
 6.5 Logging Function for a Long Time  6.6 Automatic Start and Stop Function

Use of Measured Data

Measured data can be displayed by scrolling the screen. (press [▲], [▼], [◀], [▶], [PAGE DOWN], [PAGE UP])

There are some useful functions such as search function to find the specific data, print-out function to output data displayed on the screen, and file management function to save the measured data/ setting conditions in the memory card.

 Chapter 6 Useful Functions
 Chapter 7 Data Usage
 Chapter 8 Save and Load Data

Power Source OFF

Turn off the power switch. (Press the left side switch.)

The measurement conditions, which have been set, is saved even after the power is turned off.

- In the case of turning off the power during measuring, the data will not be saved. To save in the memory card, make sure you stop measurement and turn off the power.

2.2 Set the Measurement Port (INTERFACE SETUP)

Select the measurement port which is used in the target device.

Press [1] on the top menu screen([MENU]), and select "INTERFACE."

← INTERFACE →	*SELECT*
PORT : RS232C ←	0:RS232C
MODE : DTE	1:RS485
POLARITY : NORMAL	2:TTL
LINCTRL : OFF	

← INTERFACE →	*SELECT*
PORT : RS485 ←	0:RS232C
MODE : DTE	1:RS485
POLARITY : NORMAL	2:TTL
DRVCTRL : OFF	

← INTERFACE →	*SELECT*
PORT : TTL ←	0:RS232C
LEVEL : 5.0V	1:RS485
OUTPUT : PUP	2:TTL
POLARITY : NORMAL	

- When an available port is selected, setting items varies depending on what expansion board is put on your analyzer.

■ PORT (Selecting Ports to Measure)

Select "RS232C" to measure RS-232C, "RS485" to measure RS-422/485, "TTL" to measure TTL interface.

- The action LED light of RS-232C and Others will be switched.

■ MODE (DTE/DCE Switch)

Select the specification of signal input/output for the measurement port while using Simulation or BERT function. Select "DCE" if the target device is "DTE". Select "DTE" if the target device is "DCE".

 10.2 Ports

- "DTE" is widely used in PC and data terminal devices. "DCE" is widely used in modems and terminal adapters etc.
- LED lighting for SIM DTE and SIM DCE is switched when using the Simulation or BERT function.
- When monitoring is executed, setting this is not necessary.
- Only during [RUN], signal of measurement port will be the output pin when using Simulation or BERT function.

■ POLARITY (Polarity Switch)

Normally select "NORMAL".

- In INVERT, all the signal polarity of SD and RD including the idle state of the line is inverted.

■ DRVCTRL (RS-485 driver control)

Setting of the driver IC control method when selecting "RS-485"

■ LINCTRL (Control of the control line)


Control setting of the control line when selecting "RS-232C"

- LEVEL** (signal voltage level selection)
 Selection of the signal voltage level of the measurement target when selecting "TTL". Select from 5.0V, 3.3V, 2.5V, or 1.8V depending on the specification of the target hardware.
- OUTPUT** (Output selection)
 Output selection of the simulation when "TTL" is selected. Select from "PUP" (open collector output with pull-up resistor), "NO-PUP" (open collector output without pull-up resistor), or "CMOS" (CMOS push pull output) depending on the hardware specification of the target device.

2.3 Connect to the Target Devices

Interface Port

The analyzer has RS-232C, RS-422/RS-485, and TTL ports.




Connect to RS-232C


To measure RS-232C(V.24), select "PORT" to "RS232C" at "INTERFACE".

2.2 Set the Measurement Port (INTERFACE SETUP)

On monitoring the transmission data



Connect the monitor cable (LE-25M1) and DSUB 25pin connector of RS-232C cable on the target device.



When the target RS-232C line has Dsub9pin for both ends, use optional DSUB9pin Monitor cable (LE-259M1) and connect them as above image.

[Connection of LE-25M1] () is the pin number

Dsub25pin male	Dsub25pin male	Dsub25pin female
male	male	female
(1) -----	(1) -----	(1)
(2) -----	(2) -----	(2)
(3) -----	(3) -----	(3)
(4) -----	(4) -----	(4)
.	.	
.	(connected to the same numerical pin)	
.	.	
(24) -----	(24) -----	(24)
(25) -----	(25) -----	(25)


[Connection of LE-259M1] () is the pin number.

Dsub25pin male	Dsub9pin female	Dsub9pin male
(8) -----	(1) -----	(1)
(3) -----	(2) -----	(2)
(2) -----	(3) -----	(3)
(20) -----	(4) -----	(4)
(7) -----	(5) -----	(5)
(6) -----	(6) -----	(6)
(4) -----	(7) -----	(7)
(5) -----	(8) -----	(8)
(22) -----	(9) -----	(9)

- Transmit/ Receive the test data. (Simulation)

Connect the analyzer and the target device.
Connect as following, concerning the specification of target device (DTE/DCE) and the RS-232C cable.

- DTE device -----Straight cable -----Analyzer (DCE setting)
- DCE device -----Straight cable -----Analyzer (DTEsetting)
- DTE device ----- Cross cable -----Analyzer (DTEsetting)
- DCE device ----- Cross cable -----Analyzer (DCEsetting)



Connect to RS-422 or RS-485



2.2 Set the Measurement Port(INTERFACE SETUP)

10.2 Ports


To measure RS-422/485, set "PORT" to "RS-485" at "INTERFACE".

When the RS-422/485 of the target device is connected by a connector or terminal of unique specification, confirm the pin arrangement and make a balanced transmission pair cables to connect the device to the RS-422/RS-485 terminal of the analyzer. The terminal of the analyzer is detachable, thus detach it and connect the cable and then attach it to the analyzer.

2.2 Set the Measurement Port (INTERFACE SETUP)




- Monitoring the RS-422 line between Device A and Device B




Transmission data of device A is measured in SD and reception data of device B is measured in RD..

- Simulating the transmission to the device of RS-422 port.



Set RS-422/RS-485 port to DTE mode.
Set "On" to the terminal control of RXD of RS-422-RS-485 port.

- Monitoring or Simulating the transmission to the device of RS-485.



When measuring RS-485 half duplex, connect the analyzer as one of RS-485 nodes.
When it is in simulation mode and the cable connection is like the left figure, set it to DTE mode
When connecting the analyzer as terminal (if you do not have Device C in the left picture.) set "On" to the terminal control of TXD of RS422/RS-485 port.
Transmission/ reception data on RS-485 is measured in RD.

When using for RS-485, The analyzer cannot distinguish data from device A and data from device B. Both data will shown on the SD line (when it is connected like above). In this situation, by adding timestamp, communication data visualization will improve.

2.5 Environmental Setting (Conditions)

Connect to TTL

When you measure TTL, set the “PORT” item of “INTERFACE” setting to “TTL” and connect the analyzer with the target by TTL cable such as LINEEYE optional TTL cable.




10.1 Specifications of Function and Hardware



10.2 Ports

■When you execute monitoring or send/receive simulation of TTL level line

Lead wire	Signal name	Definition
Brown	TXD	Monitor input / Simulation output of SD data.
Red	RXD	Monitor input of RD data.
Orange	RTS	Monitor input / Simulation output of RTS control line.
Yellow	CTS	Monitor input of CTS control line.
Green	GND	Signal Ground



< Connection example of UART monitoring >

Signal	Lead wire	Input/Output		Signal of target device	
		Monitor	Simulation	Monitor	Simulation
TXD	Brown	I	O	TXD	RXD
RXD	Red	I	I	RXD	TXD
RTS	Orange	I	O	RTS	CTS
CTS	Yellow	I	I	CTS	RTS
GND	Green	-	-	Signal GND	Signal GND

 “I” is an input to the analyzer. “O” is an output from the analyzer.

2.4 Characters Input

Move the cursor “■” to a space to input data using [◀],[▶].


The input space is the place which the cursor “■” is blinking at. When you input data in the middle of existing data, the characters are inserted.

As inputting is continued, the cursor is automatically moved to next space. When you edit/correct the inputted data, move to the place to be corrected using [◀],[▶]. Then, input again. To delete data, move the cursor to the beginning of data to be deleted, and press [TOP/DEL].

Inputting method (HEX or characters) is shown in the screen of analyzer.



HEX Input only




Character Input only

When inputting the transmission data for simulation, you can use both HEX input and character input in the same sentence.

◆ HEX Input

When data is inputted in a hexadecimal format, it is converted to a character in the data code set by configuration at the same time of input.




eg. ASCII

Key Input [4][1]
Data Display 04 → 41 → A

When you want to display inputted data in a hexadecimal format, press [HEX/CHAR].

◆ Character Input




When inputting data with a character, press [SHIFT]+[HEX/CHAR].

In this case, “- CHAR -” is displayed at the center of the upper part on the screen.

When you use character input, the following can be used for input; letters printed on each key and letters printed below each key.


eg.[0]



To display inputted data in a hexadecimal format, press [HEX/CHAR].

Press [SHIFT]+[HEX/CHAR] to go back to character input.

◆ Binary Input



When binary is inputted, use [0],[1],[END/X], and input every one bit where the blinking mark is displayed.

2.5 Environmental Setting (Conditions)

- The condition menu allows the setting of the environmental conditions required to operate your analyzer.



To select “CONDITION,” press [3]“CONDITION”on the top menu screen ([MENU]).

- On the condition menu, the following operating conditions can be set:

Item	Setting Conditions
0 BUFFER SELECT	Sets the allocation of partitions in the capture buffer to store the measured data. Selects ON/OFF for the protection of the capture buffer, buffer full stop function, automatic back up function, AUTO SAVE function, and automatic saving file. Selection of save device.
1 RECORD & DISPLAY CONTROL	Selects and sets ON/OFF for each display; idle time, time stamp, line status. Selects BSC translation
2 PRINT OUT CONDITION	Sets printing conditions and selects an output port.
3 REMOTE CONDITION	Sets the AUX communication conditions. Wi-Fi setting
4 AUTO RUN	Sets ON/OFF of the automatic start/ stop. Sets the starting/ending time and ON/OFF of the automatic RUN.
5 TIME & DATE SET	Sets time and date (Sets the built-in clock).
6 OTHER FUNCTION	ON/OFF of the key click sound, time until automatically turning OFF the backlight, ON/OFF of the [RUN] operation check display, ON/OFF of prohibition of measurement at the time of battery warning, ON/OFF of prohibition of simulation.

- Press a number key corresponding to each menu number to go to each setting screen or move the mark “→” to the menu number using [▲],[▼], . And then, press [ENTER].

BUFFER SELECT

Sets the capture buffer for saving the measured data.



- AREA(Buffer Partition)**
Whether a memory is used as one capture buffer or two capture buffers can be selected.
BUF0 can be used as one capture buffer.
When BUF1 and BUF2 are selected, the capture buffer is divided into two and then they are measured separately.
- PROTECT(Buffer Protection)**
This is function to prevent the data stored in the buffer memory from being inadvertently overwritten.
 - OFF: Allow to overwrite data in the capture buffer. When you load the data from a memory card, captured data will not be saved and loaded data will take over the place.
 - ON: Prevent the data stored in the buffer memory from being inadvertently overwritten.
 The write-protect can be set for each capture buffer partition.
- FULLSTOP(Ring Buffer Setting)**
This function selects the operation when the capture buffer is full.
 - OFF: Data will be overwritten from the beginning of capture buffer. In short, old data will be deleted.
 - ON: The operation will stop as soon as a memory capacity, in capture buffer partition set on “AREA” function, is full.
 -  Every reception/ transmission, timestamp/ idle time, line states consumes 4 bytes.
- DEVICE (selection of save file direction)**
Select from SD card or USB flash for the saving direction of auto save or trigger save.
 - SD: saves to SD card.
 - USB: saves to USB flash

- **BACKUP** (setting of automatic back up)
 - It automatically backs up the data of the capture memory when it stops measuring.
 - OFF: no back up
 - FILE: backs up it to the storage device indicated by "DEVICE".
 - SRAM: backs up the latest 512KB to the internal SRAM of the analyzer.
 - 📖 When set to SRAM, it reloads the data when the power turns on.
- **AUTOSAVE**(Logging Function for a Long Time)

This function saves data being measured onto a SD card or a USB flash.

📖 6.5 Logging Function for a Long Time

📖 RECORD&DISPLAY CONTROL(Record and Display Setting)

Sets additional information recorded with the data transmitted and received during the measurement.


Each kind of data is measured and recorded with the following settings of when the measurement starts.

After the end of the measurement, the data is also displayed according to the initial setting, regardless of the conditions set afterwards.

📖 6.11 Recording Function to Measure Addition Information

- **IDLE TM** (Idle Time Display Function)

The time, when SD and RD keep non-communication status and a changeless status of a signal line, is recorded in the capture buffer. It will be displayed with receipt data.




The example indicates there was an idle time of 30 to 30.9ms (at time of setting 1ms)

📖 Time Resolution : 100ms (0 to 999.9S), 10ms (0 to 99.99S), 1ms (0 to 9.999S)

- **TM STAMP**(Time Stamp Function)

The time, when the head of characters of each frame running through the communication channel is received, is recorded in the capture buffer and displayed.




The example indicates that received time of last data was 48min. 32.86 sec (at time of setting MS 10m).

📖 Display Setting : DHM (day, hour, minute) HMS (hour, minute, second), MS 10m (minute, second, 10ms)

- **LINE REC**(LineState Display)


The logical state (timing form) of the control lines and the data of SD/RD (one line for each) are displayed simultaneously.



The timing display presenting the signal condition of Line State LED's lights-on is given with logic H and that of it's lights-out with logic L.

📖 Display Setting : OFF, ON

- **LINEDISP**(Control Line Display Selection)



Four lines can be selected for the line state display.

Enter the corresponding number to select the line state.

📖 "EX" displays the logic state of TTL level from the external input "TRIGGER INI".

📖 "SQ" is for the future use and will not be displayed.

- **BSC**(Frame Translation)



The transmitted/received data can be translated and displayed.

📖 Display Setting : OFF, ON

The conditions of printing can be set.

- ☰ The setting should be done before printing out. It is not necessary for the measurement.
- ☰ In the case of setting AUX, it will be outputted as serial data through AUX port, following next “AUX CONDITION” setting. (Need to set it when using the optional printer.)

REMOTE CONDITION (Remote communication condition setting)

Setting for AUX(RS-232C) port and Wi-Fi communication

AUX

Aux setting for communication speed (SPEED), data bit length (CHAR BIT), parity bit (PARITY), and flow control (X-CONT)

- ☰ Set these items depending on those of PC or printer which is to be connected with the AUX port.

← REMOTE COND ▶	*SELECT*
AUX	
SPEED : 115200	0: 9600
CHAR BIT : 8	1: 19200
PARITY : NONE	2: 38400
X-CONT : OFF	3: 57600
W-LAN : OFF	4: 115200
	5: 230400

W-LAN

Set Wi-Fi function from “OFF”(not use Wi-Fi), STA (use through an access point), AP(the analyzer will be access point)

- ☰ Wi-Fi function is available only in Japan, USA, Canada, and EU nations where the product is needed to be compliant with RE directive (2014/53/EU).
- ☰ The analyzer corresponds with IEEE802.11b/g/n.
- ☰ You cannot remotely connect to the analyzer by AUX or USB while connecting by Wi-Fi.
- ☰ Wi-Fi setting is reflected by pushing [ENTER]. Push [ENTER] when you finish the Wi-Fi setting such as SSID.

< STATION >

← REMOTE COND ▶	*SELECT*
AUX	
SPEED : 115200	0: OFF
CHAR BIT : 8	1: STA
PARITY : NONE	2: AP
X-CONT : OFF	
W-LAN : STA	

Item	Description
SSID	Identifier of the access point
PASSWORD	Security key (encryption key)
DHCP	ON/OFF of DHCP
IP-ADDR	IP address of the analyzer
NETMASK	Subnet mask of the analyzer
GATEWAY	Default gateway
PORT	Port number of the analyzer to be connected

← REMOTE COND ▶	*STATION*
SECURITY: WPA/WPA2	
SSID :	
PASSWORD :	
IP-ADDR : 0. 0. 0. 0	
NETMASK : 0. 0. 0. 0	
GATEWAY : 0. 0. 0. 0	

← REMOTE COND ▶	*INPUT*
PORT : 10101	SET SERVER PORT
	(1~65535) (DECIMAL)

- ☰ When you connect through internet set GATEWAY.
- ☰ The PASSWORD will be shown by ● after entering it thus you cannot confirm the setting

- ☰ “IP-ADDR”, “NETMASK”, and “GATEWAY” are need to be set when DHCP is invalid.

< AP >

← REMOTE COND ▶	*SELECT*
AUX	
SPEED : 115200	0: OFF
CHAR BIT : 8	1: STA
PARITY : NONE	2: AP
X-CONT : OFF	
W-LAN : AP	

Item	Description
SECURITY	Select authentication protocol from the followings; OPEN, WPA, WPA2, or WPA/WPA2
SSID	Identifier of the analyzer Initial value is LE_xxxxxxxx (xxxxxxx is serial number of the analyzer)
PASSWORD	Security key (encryption key) Initial value is @xxxxxxx# (xxxxxxx is serial number of the analyzer)
CHANNEL	Channel to be used for Wi-Fi
PORT	Port number of the analyzer to be connected

← REMOTE COND ▶	*AP*
SECURITY: WPA/WPA2	
SSID : LE_99999999	
PASSWORD : ●●●●●●●●	
CHANNEL : 11	

← REMOTE COND ▶	*INPUT*
PORT : 10101	SET SERVER PORT
	(1~65535) (DECIMAL)

- ☰ Set the CANNEL not to interfere with other wireless applications..

AUTO RUN (Automatic Start and Stop)

Can start and stop measurement repeatedly. Can also be in the RUN state as soon as the power is on.

← AUTO RUN ▶ [10/20 16:58]	*SELECT*
MODE : MONTHLY ←	0:MONTHLY
RUN TIME:OFF	1:DAILY
STOPTIME:OFF	2:HOURLY
P-ON RUN:OFF	

 Using AUTOSAVE with “APPEND ON” is useful.

 6.5 Logging Function for a Long Time (AUTOSAVE)

TIME & DATE SET

The following procedure should be followed in order to set the built-in clock.

← TIME & DATE ▶ PRESENT [16 10/20 16:58:52]
DATE '16 10/20
TIME 16:58:36
←,→,↑,↓ SELECT & INPUT DATA

1. The current time and the date are displayed in the first line on the screen.
2. Move the cursor to the flashing figure to be changed with [←],[→],[▲] and [▼].
3. Input with [0] to [9].
4. The date is displayed as year(last two figures)/month/day,and time is displayed as hour: minute:second(the 24 hour display).
5. Press [ENTER] to set the new value.
When you abort the clock setting, press not [ENTER] but [MENU] in order to go back to the top menu screen.

 When the Appointed Time Automatic Start and Stop Function is used, make sure the current time and the date are inputted correctly.

OTHER FUNCTION

Sets the following: sounding a buzzer, turning off the backlight automatically, battery warning.

■ KYESOUND (Key Click Sound Setting)

← OTHER FUNC ▶	*SELECT*
KEYSOUND:ON	SIMULATION
BL OFF : 0	& BERT LOCK
RUN CHK :ON	0:OFF
BATTWARN:ON	1:ON
SIM LOCK:ON	

KEYSOUND means key click sound.

■ BL OFF (Backlight Setting)

← OTHER FUNC ▶	*INPUT*
KEYSOUND:ON	SET
BL OFF : 0	BACKLIGHT
RUN CHK :OFF	AUTO OFF
BATTWARN:ON	TIME
SIM LOCK:OFF	(0~60) min
	(DECIMAL)
	0=INFINITE

The time, when backlight is turned off automatically, can be set. If key operation is not executed within set time (from 1 to 60), backlight will be turned off automatically. It will not be turned off automatically, if "0" is input.

 [SHIFT]+[DISPLAY MODE] switches lighting and lights-out

■ RUN CHK (RUN key check)

← OTHER FUNC ▶	*SELECT*
KEYSOUND:ON	RUN KEY
BL OFF : 0	CHECK
RUN CHK :OFF	0:OFF
BATTWARN:ON	1:ON
SIM LOCK:OFF	

Displaying the message confirming start of measuring or not when “RUN” key is pressed.

 It may avoid starting measurement by accident and protect the measured data.

■ BATTWARN (Operation of While Battery Warning is Active)

← OTHER FUNC ▶	*SELECT*
KEYSOUND:OFF	BATTERY
BL OFF : 1	WARNING
RUN CHK :OFF	ERROR
BATTWARN:ON	0:OFF
SIM LOCK:OFF	1:ON
	2:STOP

Even while battery warning is active, whether or not measuring operation can take place.

 It is possible to continue measuring even during battery warning. However, you are advised to use the AC adapter.

■ SIM LOCK (Simulation Lock)

← OTHER FUNC ▶	*SELECT*
KEYSOUND:ON	KEY CLICK
BL OFF : 0	SOUND
RUN CHK :OFF	0:OFF
BATTWARN:ON	1:ON
SIM LOCK:OFF	

Selects ON/OFF of actions of simulation or BERT.

 It prevents a mistaken [RUN] operation from affecting the target line or communication system.

2.6 Communication Condition Setting (Configuration)

Your analyzer needs to be set up adjusting communication conditions like communication channels, protocols for tested device, communication speed and so on.

Press [MENU] to display the top menu and then press [0] "CONFIG" to set the communication conditions (configuration).

4CONFIGURATION>	*SELECT*
PROTOCOL :ASYNC ←	0:ASYNC
S-SPEED :9600	1:SYNC-BSC
R-SPEED :9600	2:HDL C-SDLC
CODE :ASCII	3:ASYNC(PPP)
CHAR BIT :8	4:MODBUS
PARITY :NONE	
PUSH PAGE DOWN	PUSH SHIFT+PAGE DOWN



Communication Protocol Setting

Select "PROTOCOL" as your target device.

"PROTOCOL"	Communication protocol of target device	Description
ASYNC	Asynchronous	Communications which uses start and stop bits. Ex.) PC COM port, UART communication
PPP	PPP (Asynchronous typed)	Asynchronous which uses flag characters (7Eh). Ex.) PPP communication used for WAN etc.



Communication Condition Settings

Communication condition settings are different for each protocol. Set the necessary conditions.

Item	Description	ASYNC	PPP
S-SPEED	Channel speed on the SD side	●	●
R-SPEED	Channel speed on the RD side	●	●
SPEED	Bus line speed		
CODE	Display code	○	○
CHAR BIT	Character bit length	●	
PARITY	Parity bit	●	
STOP BIT	Stop bit	○	
FCS	Frame check		○
SUPPRESS	Suppress character		○
BCC	Block check	○	
BGN CHAR	BCC calculation start character	○	
END CHAR	BCC calculation end character	○	
ITB CHAR	ITB character	○	
TRANSPRT	Transparent mode	○	
DLE CHAR	Data Link Escape character	○	
SEQUENCE	Character bit transmission sequence	○	
FRM TIME	Frame end judgment time	○	
FRM END	Frame end character	○	


- is necessary to set. ○ is needed to be set in some measuring conditions and test conditions.
- When communication conditions to measure are unknown, "AUTO CONF" can be selected.

Move the cursor "←" by [▼], [▲], [PAGE DOWN], [PAGE UP] and select the item by [◀], [▶], [0] ~ [F].

- **TRANSPRT**
Selects On/Off of transparent mode to calculate.

- **DLE CHAR**
Sets a DLE character for transparent mode in HEX.

- **SEQUENCE**
Sets bit sequence.



In order to check normal protocols except for some ones, "LSB FIRST" needs to be set.

- **FRM TIME**
Sets the time of non-communication state which is judged as a frame end at between 1ms and 100ms.
Default is 5(ms). Sets the bigger number when measuring low speed data or data with few time stamp.
- **FRM END**
Sets the frame end characters up to 2 characters in HEX.
Default is "None" and frame ends at the time set in "FRM TIME".

Chapter 3 Monitor Function

The purpose of the monitor function is to record communication data into the capture buffer without impacting on a communication channel. Also, it is to display clearly following each communications protocol. Not only communication data but also time stamp for data frame and idle time are recorded. As a result, error time and time out conditions are investigated. Moreover, the trigger function, which detects specific communication conditions, and filter function for specific address frame, which makes a memory effectively used, are included.

3.1 Online Monitor Function (ONLINE)

Setting




Move “▶ ◀” to “ONLINE” on the top menu screen.
Configuration (communication conditions) needs to be set in advance.

2.6 Communication Conditions Setting

Operation

To start measurement, press [RUN]. And, the RUN LED is lit. Then, data will be stocked into the capture buffer with it displayed on the screen. One set of two lines of transmission and reception data is displayed. And SD data is displayed on “▶” and RD data is displayed on “◀”.



Ex.) When measuring on RS-232C port

“▶” Row Data inputted from RS-232C port Pin 2 (SD)

“◀” Row Data inputted from RS-232C port Pin 3 (RD)

When SD and RD are generated at the same time, they are displayed on the same column. “█” is the mark to indicate the place which new data is displayed at. And data on the left side of this mark is new one (displayed only during RUN).

■ Error Data and Special Character

Code	Name	Meaning
	Parity Error	Displayed when parity is incompatible.
	Framing Error	Displayed when stop bit is “0.”
	Parity & Framing Error	Parity error and framing error are generated at the same time.
	Overrun Error	Displayed when your analyzer cannot process data.
	Break	Displayed when all of start bit, character bit, (parity bit), stop bit are “0.”
	Block Check Code (Normal)	Displayed when BCC or FCS is normal.
	Block Check Code (Abnormal)	Displayed when BCC or FCS is abnormal.
	Multiprocessor Bit	Displayed when multiprocessor bit is “1.” *

■ To stop measurement, press [STOP].

- When [ENTER] is pressed, the motion on the display screen temporarily seems stopped while measurement has continued even after being pressed.
 - ☞ The RUN LED remains lighting.
 - ☞ Operations like capturing data, a trigger, and etc. are not influenced.
 - ☞ During screen being stopped temporarily, "PAUSE" will be displayed at "FUNCTION" part of state display on the last line of the screen.
- In order to toggle this state, press [ENTER] again.
 - ☞ "PAUSE" will be not displayed at "FUNCTION" part of state display on the last line of the screen.


3.2 Analog and Delay Time Function

DELAY function simultaneously supplies two functions:

1. Measure the delay time between one condition of the interface signal and the another.
2. Measure the voltage (MAX. MIN. Current) of the signals of RS-232C or TTL.

Setting

- Sets the start/stop conditions of delay time. When measuring the voltage of RS-232C or TTL, you do not need to set this.



Move "▶" "◀" to "DELAY" on the top menu screen.

To select "DELAY" on the setup window, press [6] or [Enter].

Set the start/stop conditions of delay time by setting nine signals (SD, RS, ER, RD, CS, DR, CD, CI and EX (external signal)). Set them with [1](ON), [0] (OFF), [X](don't care) moving a cursor with [◀], [▶], [▲], [▼]

- ☞ ON state : RS-232C voltage level is +3 or higher (space).
- ☞ OFF state : RS-232C voltage level is -3 or lower (mark or NC).
- ☞ Although SQ is displayed on the screen because of compatibility with old models, the setting will be ignored.


Action

-ANALOG INPUT (V, 24)-				-LINE DELAY-			
NOW	MIN	MAX	TIMES	CUR	MIN	MAX	AVE
SD +0.0V	-5.5V	+1.7V	0	0.0mS			
RD -0.2V	-5.5V	+1.4V	0	0.0mS			
ER +0.0V	-5.1V	+5.7V	0	0.0mS			
CD +5.5V	-5.5V	+5.8V	1	0.0mS			
			0	ASCII	2.048M	2.048M	

Press [RUN] to display the value of voltage measured (ANALOG INPUT VOLTAGE) and the delay time of the interface signals(LINE DELAY) in real-time.

- Delay Time Measurement

Delay time means the time between the start and stop condition of the signals at the resolution of 0.1ms.



- ☞ The start/stop conditions are established when the nonconformity of the two conditions becomes the conformity of those. Thus, start/stop conditions will not be established when they are conformed from the beginning.
- ☞ The change of signals within 0.1 ms cannot be sometimes detected.

Display

- Display of the signal voltage measured in RS-232C level
 - shows simultaneously the voltage values of the current, MAX and MIN of each signal of SD, RD, ER (RS when selecting TTL), and CD (CS when selectinf TTL).
 - ☞ The signal input range is +/-15V, and the resolution is 0.1V.
- Display of delay time
 - shows the delay time between start and stop condition of the current value, Max, Min, Average and number of times (how many times).
 - ☞ When the value at "CUR" is over the signal input range, "OVER FLOW" is displayed. If the start condition is established again, the counter is cleared and measurement will start again. However, the value of MAX and average are not assured.

Chapter 4 Simulation Function

The simulation function is the tool that makes your analyzer operate as a device communicated by tested devices, and that executes a test for transmission and reception following protocols.

Even if communicated devices are not prepared at the first step in developing, the testing like real operation will be able to be executed. You can check communication procedure in our original "MANUAL mode. A margin can be evaluated at staggered communication speed on purpose because appointed communication speed can be set. Moreover, error processing response can be checked with tested data which includes parity error data.

- **MANUAL Mode**

Registered data of the transmission table corresponding to operation keys [0] to [F] is transmitted one touch every time each key is pressed. Communication procedure can be easily tested with the trigger function checking response from the developed devices through the monitor function. In addition, by pressing [SHIFT] and one key from [0] to [D] fixed data corresponding to each key can be transmitted. Also, pressing [SHIFT] and [E],[F] makes the signal line of RS/CS or ER/CD set ON/OFF.

- **FLOW Mode**

As a transmitter or a receiver, X-ON/OFF flow control and control line handshake can be simulated. In the transmission mode, the number of transmission data for sixteen times can be displayed from a start to an interrupt request. On the other hand, in the reception mode, two things can be appointed. One is the number of reception data of until an interrupt request is submitted for transmitting. The other is time of until a start request is submitted for transmitting.

- **ECHO Mode**

Reception data is turned back in your analyzer. It is used for testing a display terminal and a communications terminal.

4.1 Preparation for Simulating

Registration of Transmission Data (DATA TBL)

At the time of using the simulation function, transmitted data is registered.



Select "DATA TBL" ([9]) of the setup menu in the simulation. Transmission data table has 160 kinds from No.00 to No.9F. The total of it can be set up to max. 16384 characters.


If there is data registered in each table, the first eight characters will be displayed.

<Data to be Registered>

The characters, which are inputted and displayed, are treated as the code being set on a data code (CODE: item) of the configuration menu. After setting required data code, inputting and editing should be executed. And, on the display screen for registering transmission data, the character display cannot be changed by SHIFT IN and SHIFT OUT.

The effective data entered is only bit which is set in the character bit length. Others at higher positions are ignored.

<Method of Registration>>



Enter the table group (GROUP) and table number to be set and changed. Then, press [Enter] to display the data entry screen.

Registered data will be displayed on the screen. A cursor position is where "█" is blinking. "REMAIN", which indicates the rest of buffer for transmission data, will appear on the upper right of the screen. And also, "POSITION", which indicates the cursor position, will appear below "REMAIN".

1. Data Entry

Move a cursor where you wish to enter data using a cursor key. A cursor position is the place which "█" is blinking at. To modify or add entered data, move the cursor to the position and enter the characters. To delete it, move the cursor where you wish to delete it, and press [TOP/DEL]. Then, it will be deleted, and the characters after the deleted character will be moved forward. An input is executed in HEX or character.


2.4 Character Input

2. BCC and FCS Addition

If setting other than "NONE" in "BCC" item or "FCS" item at Configuration, calculation for BCC or FCS will be executed by pressing [SHIFT] + [ENTER] after finishing inputting. Finally, BCC or FCS will be inserted. In the case of BCC, BCC will be inserted after "END CHAR" because a calculation, which is between "BGN CHAR" and "END CHAR" that is set in the configuration, is executed.


eg.)

◆ Configuration Setting (ASCII)



BCC :Sets "LRC ODD"
BGN CHAR :Sets "(02h)"
END CHAR :Sets "(03h)"


◆ Register data in the data table



"S_X ABCDEFG E_X" is registered to TABLE No.00.

◆ Executing a Calculation of BCC

Press [SHIFT] + [ENTER] on the display screen of the data table.



BCC is calculated between "(02h)" and "(03h)," and then BCC (BCh) is inserted behind "(03)" = "EX."

In order to modify data which has been calculated as BCC (FCS), or the setting of BCC (FCS), press [SHIFT] + [ENTER] to recalculate. Then, recalculated BCC (FCS) will be overwritten and appear.

3. Parity Error and Multiprocessor Setting

At first, move a cursor where you want parity error to be generated or where you want multiprocessor bit to be set to 1. And then, press [SHIFT] + [E]. The setting will be completed.



eg) The setting of “A”

Move a cursor to “A” and press [SHIFT]+[E].

A highlighted “A” will be displayed.

After setting, highlighted characters will be displayed. In order to undo this, press [SHIFT]+[E] again.

<Method of Useful Data Editing>

■ Inputting Altogether (Copy)

This is the function to input plural characters once or repeatedly by copy and paste.

eg) Copying characters from A to L, and inputting them altogether




① Select the first character with a cursor and press [ENTER]. “SIZE” will appear on the upper right of the screen instead of “REMAIN.” And then, as the cursor is moved with characters selected, the number of selected characters will be displayed next to “SIZE.”

② Move the cursor from “A” toward “M” using a cursor key, selecting letters.

* In this case, the cursor on “M” is blinking.



③ To register letters from “A” to “L,” press [END/X]. They are registered in an editing memory.



④ Press [END/X] again to paste.

Registered data will be inserted to the next part of the cursor position.

After this, unless it is changed, it will be pasted repeatedly as [END/X] is pressed.

☞ There is capacity for 256 characters in an editing memory. When more than that is registered, 257th character and afterwards are truncated.

■ Deleting Altogether

This is the function to delete plural characters at the same time.


① Select the first character with a cursor and press [ENTER]. “SIZE” will appear on the upper right of the screen instead of “REMAIN.” And then, as the cursor is moved with characters selected, the number of selected characters will be displayed next to “SIZE.”

② After a cursor is moved where to be deleted, press [TOP/DEL]. The highlighted character string but last blinking character will be deleted. Deleted characters are registered in an editing memory. Therefore, even when they are needed after deleted, [END/X] will help you to let them appear again.

(Possible to register up to max. 256 characters)

■ Copying Table Data

To use the special editing functions “COPY TABLE,” press [SHIFT]+[MENU] on the data entry screen.



① Select “COPY TABLE.”

And press the table No. to be copied.



② Press [ENTER].


Then, data of the selected table No. will be added to the previous part of a cursor position on the character.

Above the screen indicates that the data from “A” to “Z” is registered in TABLE0 and also the data from “0” to “9” is registered in TABLE2, and then that a cursor has been moved to “O” and data in TABLE2 has been copied and pasted there.

■ Copying Buffer

To use the special editing functions “BUFFER COPY,” press [SHIFT]+[MENU] on the data entry screen.

1.The head of data to be copied is adjusted on the upper left of the display screen of monitored data scrolling.



2.Select “COPY BUFFER” and select the SD side or the RD side.


3.Set the number of the characters to “SIZE” item.

4.Press [ENTER]. The number of the characters appointed from that data will be inserted behind the cursor position.

- ☞ It is copied. IDLE TM and TM STAMP are ignored.
- ☞ When transmission data table is full, operation will stop.

■ FILL

Data from characters appointed in “BEGIN” to ones appointed in “END” can be inputted for the number of the characters inputted in “SIZE.”



eg.)
 BEGIN : 01
 END : 03
 SIZE : 08

Press [ENTER]. Then, the following data will be inputted at a cursor position.

01 02 03 01 02 03 01 02

If BEGIN < END, a character from BEGIN toward END will be inputted increasing one by one till the number of a character set in “SIZE” is filled.

If BEGIN > END, a character from BEGIN toward END will be inputted decreasing one by one till the number of a character set in “SIZE” is filled.

If BEGIN = END, a common character set in both BEGIN and END will be inputted till the number of a character set in “SIZE” is filled.

When the transmission data table is full, operation will stop.

■ Fixed Transmission Data

Special characters like ENQ, ACK, etc. can be inputted with [SHIFT] + one key from [0] to [D] . They are inputted in data code being set in the configuration.

[SHIFT]+[0]	:ENQ	[SHIFT]+[7]	:RVI
[SHIFT]+[1]	:ACK	[SHIFT]+[8]	:TTD
[SHIFT]+[2]	:NAK	[SHIFT]+[9]	:‘ FOX ’ Message (*1)
[SHIFT]+[3]	:WACK	[SHIFT]+[A]	:‘ MSG1 ’ Message (*2)
[SHIFT]+[4]	:EOT	[SHIFT]+[B]	:‘ MSG2 ’ Message (*3)
[SHIFT]+[5]	:ACK0	[SHIFT]+[C]	: DC1(11H)
[SHIFT]+[6]	:ACK1	[SHIFT]+[D]	: DC3(13H)

*1 ‘FOX’ :THE QUICK BROWN FOX JUMPS OVER A LAZY DOG 0123456789.

*2 ‘MSG1’:SX0123456789ABCDEFGHIJKLMNPNOPQRSTUVWXYZ^{Ex} **BCC**

*3 ‘MSG2’:0123456789ABCDEFGHIJKLMNPNOPQRSTUVWXYZ **R-F**

◆ The values (hexadecimal) corresponding to entries of the keys [SHIFT] + one key from [0] to [B] vary depending on the setting for data code of the configuration.


◆ Characters, which are not defined in the code table, are ignored.

◆ Entries with the keys [SHIFT] + one key from [0] to [8] cause the following values to be set.

	ASCII(JIS)	EBCDIC(EBCDIK)	Transcode	Others
ENQ	05	2D	2D	-
ACK	06	2E	3C	-
NAK	15	3D	3D	-
WACK	10 · 3B	10 · 6B	1F · 26	-
EOT	04	37	1E	-
ACK0	10 · 30	10 · 70	1F · 20	-
ACK1	10 · 31	10 · 61	1F · 23	-
RVI	10 · 3C	10 · 7C	1F · 32	-
TTD	02 · 05	02 · 2D	0A · 2D	-

Driver Control [RS-422/485] (DRVCTRL)

Select the method to control RS-422/485 transmission driver IC when simulating on RS-422/485 port.



Set "DRVCTRL" item of "INTERFACE" ([1]) on the top menu screen.

 2.2 Set the Measurement Port (INTERFACE SETUP)

OFF : Select when testing RS-422, X.20/21, RS-449 and V.35 in full duplex. Driver IC will always be in an enable state after starting test.

MANUAL : When ER (DTE) or CD (DCE) is ON, the driver will be in an enable state. And when ER (DTE) or CD (DCE) is OFF, the driver will be in disable (high impedance) state. It is used to control driver IC by setting ON/OFF of ER and CD in MANUAL.

 When "LINECTRL" is set ON, the driver IC will be controlled

 When "LINECTRL" is set OFF, the initial state of ER (DTE) or CD (DCE) at the start of simulation is as follows:

Simulation mode	Initial State of Driver
MANUAL Mode	High impedance state
FLOW Mode	Enable
ECHO Mode	Enable

AUTO : Select "AUTO" when testing RS-485 in half duplex. The driver automatically becomes "Enable" only while transmitting the test data, and the driver will automatically become "Disable" after about 1 to 3 bits is delayed after data transmission. However, because of the processing time, there is a delay of 400u seconds at least.

Terminator for RS-422/485 Port



When a simulating test for transmission/reception is executed through RS-422/485 port, also when your analyzer is put at a terminal position of communication for one to one communication, the terminator need be connected. In general, at the time of RS-422, the terminator only of the input signal line on your analyzer is connected. Moreover, at the time of RS-485, the terminators of all the signal lines on your analyzer are connected.

 2.3 Connect to the Target Devices

Method of connecting terminators


Take out the interface sub-board and set the jumper to "1" side to connect the terminator.

JP1 is the jumper pin of the terminator for TXD side and JP2 is for RXD side.



[Method of taking out and inserting interface sub boards]

- ① At first, screw a sub board off, and take it out.
- ② Set the jumper.
- ③ Finally, insert the sub board into a slot, and screw it on.



Controlling a Control Line (LINECTRL)

The signal state of control lines (RS, ER, CS, CD) and timing of data transmission can be controlled automatically when simulating. Depending on the interface mode (DTE/DCE), the action will be different.

Press [Menu] -> [1]"INTERFACE" and set "MODE" to "DTE" or "DCE". To have automatic control of control lines, set "LINECTRL" to "ON".

 Automatic control will not be operated if setting "LINECTRL" to "OFF".

DTE


```

┌ INTERFACE ──┐   *SELECT*
PORT   :RS232C  0:OFF
MODE   :DTE     1:ON
POLARITY:NORMAL
LINECTRL:ON
└─┘             └─┘
PUSH PAGE DOWN
    
```

To set following items, press [PAGE DOWN].

```

┌ INTERFACE ──┐   *INPUT*
DELAY TH: 10     SET TIME
RS ON  : 10      (0~9999)ms
SD SEND: 100
RS OFF : 100
ER SW  : ON
└─┘             └─┘
PUSH PAGE UP
    
```



Items	Description
RS ON	Time Between the start of transmission operation and RS "ON."
SD SEND	Time between CS "ON" and data transmission to the SD side.
RS OFF	Time between the end of data transmission to the SD side and RS "OFF."
ER SW	ON/OFF of ER signal when testing.


 ON: active, OFF: non-active

(Example of Data transmission "ABC")

If set as follows:

```

┌ INTERFACE ──┐   *INPUT*
DELAY TH: 10     SET TIME
RS ON  : 10      (0~9999)ms
SD SEND: 20
RS OFF : 30
ER SW  : ON
└─┘             └─┘
PUSH PAGE UP
    
```




[RUN]



```

┌ IDLE IDLE IDLE ABC IDLE IDLE ──┐
└─ 0010 0010 0020 0030 0051 ──┘
RS
CS
CD
ER
0 ASCII 9600/9600
    
```



Target device (DCE) makes CS "ON" after 10 seconds from RS "ON". And it makes CS "OFF" after 51 seconds from RS "OFF".

DCE


```

┌ INTERFACE ──┐   *SELECT*
PORT   :RS232C  0:OFF
MODE   :DCE     1:ON
POLARITY:NORMAL
LINECTRL:ON
└─┘             └─┘
PUSH PAGE DOWN
    
```

To go to the screen for setting the control line, press [PAGE DOWN].

```

┌ INTERFACE ──┐   *INPUT*
DELAY TH: 10     SET TIME
CS ON  : 10      (0~9999)ms
CD ON  : 100
RD SEND: 100
CD OFF : 100
└─┘             └─┘
PUSH PAGE UP
    
```




Items	Description
CS ON	Time between RS "ON" and CS "ON."
CS OFF	Time between RS "OFF" and CS "OFF."
CD ON	Time between the start of transmission operation and CD "ON."
RD SEND	Time between CD "ON" and the start of data transmission to the RD side.
CD OFF	Time between the end of data transmission of the RD side and CD "OFF."

 ON: active, OFF: non-active.


```

┌ INTERFACE ──┐   *INPUT*
DELAY TH: 10     SET TIME
CS ON  : 10      (0~9999)ms
CD ON  : 51
RD SEND: 30
CD OFF : 5
└─┘             └─┘
PUSH PAGE UP
    
```



```

┌ INTERFACE ──┐   *INPUT*
DELAY TH: 10     SET TIME
CS ON  : 50
CD ON  : 30
RD SEND: 5
CD OFF : 5
└─┘             └─┘
PUSH PAGE UP
    
```



4.3 Flow Control Test(FLOW)

In the flow control test, your analyzer works as a transmitter or a receiver. It can transmit data following a control signal. Also, it can receive data returning a pseudo-control signal.

(Control Signal : Control line handshake such as RS, CS, etc. or X-ON/X-OFF code)

Setting



Move “▶ ◀” to “FLOW” on the top menu screen ([MENU]).

Set the configuration (communication condition) in advance.

2.6 Communication Condition Setting

To select “FLOW,” press [ENTER] or [C].

Flow Control is available only when “PROTOCOL” in Configuration is set to “ASYNC”.



- Set the following items below.

Item	Description	Range of Selection	Remark
TEST MODE	Test motion mode	SEND: Transmission mode (Reception test) RECV: Reception mode (Transmission test)	
INITIAL	Initial state of a control signal	ON/OFF	When “control” is “LINE,” it indicates controlling state. When it is “Char.” it indicates controlling code state.
CONTROL	Control signal selection	CHARACTER/LINE	
X-ON	Requesting code for transmission start	HEX 1byte	Only when “CHARACTER” is selected in “CONTROL.” (*1)
X-OFF	Requesting code for transmission interruption	HEX 1byte	
WATCH	Monitoring control line	CS/RS CD/ER	Only when “LINE” is selected in “CONTROL.”
OPERATE	Operating control line	RS/CS ER/CD	
TABLE No	Transmission table No..	00~9F	Only when “SEND” is set to “TEST MODE.”
IDLE TM	Transmission character space	0 to 99999 1msec. unit	
ON COUNT	The number of a reception character of until interruption request is transmitted from starting	1~999999	Only when “RECV” is set to “TEST MODE.”
OFF TM	Starting request for transmission + Response time	0 to 99999 1msec. unit	

*1 If the same codes are set in both X-ON and X-OFF, normal motion is not guaranteed.

- “TEST MODE:”

The motion mode is selected.

- [0]“SEND.” Mode to match data with a control signal and to transmit it from your analyzer.
- [1]“RECV.” Mode to control a control signal while your analyzer receives data.

- “INITIAL”

The initial state of a control signal is set.

- [0]“OFF” Impossible state for transmission.
- [1]“ON” Possible state for transmission.

- “CONTROL”

Character control or line control is set.

4.4 Echo Back Test (ECHO)


- The echo back test is the function that makes received data repeatedly transmitted from your analyzer.

Setting



Move "► ◀" to "ECHO" on the top menu screen.

Set the configuration (communication condition) in advance.



2.6 Communication Condition Setting

Press [D] or [Enter], to select "ECHO"

BUFFER returns the received frame with the time interval according to the set time (from 0 to 99999) at "RESPONSE", when receiving one frame.


9.3 Frame

CHAR. returns the received data by a character when receiving one data.

☰ This is available only when "ASYNC" is selected at Configuration..

LOOP loops back the signals of SD-RD, RS-CS, ST1-RT, or what supplied at "LOOP" (ER-DR or ER-CD).


☰ It loops back in the hardware of analyzer..



Action

Press [RUN] to start receiving data and then the analyzer acts according to the setting at "TEST MODE."

- **BUFFER** returns the received data per frame according to the Configuration.
e.g.) "RESPONSE" = 20ms



- **CHAR.** returns the received data with the data bit and Parity/MP bit.
e.g.) communication speed = 115.2kbps



☰ It may delay the reception because of the timing of reception.

- **LOOP** loops back the signals in the analyzer according to the setting of "INTERFACE."
e.g.)

When loops back SD-RD; "PORT"=RS-232C, "MODE"=DTE,

SD(2pin) -> Input IC -> connected in the analyzer -> RC-232C driver in the analyzer -> RD(3pin)



Chapter 5 Bit Error Rate Test (BERT) Function


The analyzer has the ability to send the test pattern and to compare the received data to the test pattern. This makes it possible to evaluate quality of a data communication line, including modems, and to locate the point of trouble in the data communication line by means of loop-back test or interactive test.

When “PROTOCOL” is set to “PPP” the function cannot be performed.

Cable Connection

Connection for loop-back test


In the loop-back test, the test pattern data sent from the analyzer is sent back at each node of the communication channel. This enables an evaluation of the round-trip path over the communication channel via the node (loop-back point), and locates a trouble point by testing while changing the loop-back point.




The loop-back point can be usually set and changed in a modem by using the self-test function of the normal modem. (Consult the instruction manual of the modem you use.)

Connection for interactive test

In an interactive test, the communication channel is tested by connecting the analyzer to a device which has the BERT function equivalent to that of the analyzer, and the same test patterns are sent from both sides. This allows testing of the send and the receive lines independently.



Setting



Move “▶ ◀” to “BERT” on the top menu screen ([MENU]).

Set the configuration (communication conditions) in advance.

2.6 Communication Condition Setting

To select “BERT,” press [8] or [ENTER].

1. Set according to the table below.

Item	Meaning	Setting range
TEST MODE	Test mode	CONTINUE/R-BIT/RUNTIME/REPEAT
PATTERN	Test pattern	63/511/2047/MARK/SPACE/ALT/DBL-ALT/1IN4/1IN8/1IN16/3IN24
FLOWCTRL	RTS/CTS Flow control	ON/OFF

2. Place “◀” mark on “TEST MODE” to select the kind of the test mode.

Setting	Name	Description
0	CONTINUE	Continuous measurement
1	R-BIT	Continues the test until the number of effective received bits exceeds the designated value.
2	RUN TIME	Continues the test until the measurement time exceeds the designated value. (The lapse of time after synchronization has been established.)
3	REPEAT	Measures BERT measurement of the specific time repeatedly.

◀ BERT ▶ TEST MODE: R-BIT COUNT : 1.0E3 PATTERN : 63 FLOWCTRL : OFF	*SELECT* 0 CONTINUE 1 R-BIT 2 RUN TIME 3 REPEAT
◀ BERT ▶ TEST MODE: RUN TIME SEC : 60 PATTERN : 63 FLOWCTRL : OFF	*SELECT* 0 CONTINUE 1 R-BIT 2 RUN TIME 3 REPEAT
◀ BERT ▶ TEST MODE: REPEAT RESOLUT : 10 PATTERN : 63 FLOWCTRL : OFF	*SELECT* 0 CONTINUE 1 R-BIT 2 RUN TIME 3 REPEAT

- ◆ When R-BIT is selected, “COUNT” is displayed under “TEST MODE” to select the designated value of the number of effective received bits. Place the “◀” mark on “COUNT” to enter the number of bits displayed in the given list “SELECT” with the numerical keys.
- ◆ When RUN TIME is selected, “SEC” is displayed under “TEST MODE” to select the designated value of the measurement time. Place the “◀” mark on “SEC” to enter the measurement time by the numerical keys.
(Max. 99999999sec)
- ◆ When selecting REPEAT, “RESOLUT” which can select the specific value of the measurement unit time is displayed under “TEST MODE”.
Place “◀” mark on “RESOLUT” to specify the measurement time of 1 time by units of minutes. (up to 1440 minutes = 24 hours)

3. Place “◀” mark on “PATTERN” to select a transmitting test pattern data.

Setting	Name	Description
0	63	$2^6 - 1$ (Random code generated by generation polynomial $X^6 + X + 1$)
1	511	$2^9 - 1$ (Random code generated by generation polynomial $X^9 + X^4 + 1$)
2	2047	$2^{11} - 1$ (Random code generated by generation polynomial $X^{11} + X^2 + 1$)
3	MARK	ALL 1
4	SPACE	ALL 0
5	ALT	10..
6	DBL-ALT	0011..
7	1 in 4	1000..
8	1 in 8	10000000..
9	1 in 16	1000000000000000..
A	3 in 24	010001000000000000000100..

4. Place “◀” mark on “FLOWCTRL” to set RTS-CTS flow control.

On: When the analyzer is in DTE mode, it transmits the data while CTS is active, and stops transmitting while non-active.

When the analyzer is in DCE mode, it transmits the data while RTS is active, and stops transmitting while non-active.

Off: Data transmission is always available.

■ Relation with the PROTOCOL setting

The communication speed and character bit length are determined by the setting of the “PROTOCOL” of configuration.

◆ In the Case of ASYNC

Item	Meaning
S-SPEED	Transmission speed of test pattern
R-SPEED	Receiving speed of a test pattern
CHAR BIT	Character bits length of test pattern data
STOP BIT	Stop bits length of transmission test pattern data
Other setting items	Irrelevant

📄 Test pattern is divided to the designated value of CHAR BIT and a start bit and a stop bit are added to each unit. The added start bit and stop bit are not measured.

5.1 Start and End a Measurement

Start

Press [RUN] to display the BERT results screen after the results of the previous measurement cleared, and a new measurement starts.

- Transmission Transmission of the test pattern starts from the SD side when DTE is set, or from the RD side when DCE is set. The following signals are turned on simultaneously when the transmission starts.
When DTE is set : RS, ER When DCE is set : CS, DR, CD
 - ☰ It is possible to stop updating the result display by pressing [ENTER] during measurement. However, at the time of REPEAT measurement, only the number of measurement unit time displayed at the lower part of the screen is updated.
- Receiving “SYNC SEARCH” is displayed until the initial pattern is detected and synchronization, “SYNC SEARCH” disappears and measurement starts.
 - ☰ Every time [0] is pressed during a measurement operation (transmission of test pattern), a test pattern including one error bit is sent. Every time [1] is pressed, a test pattern including five errors is sent.

End

Press [STOP] to stop the measurement. When “TEST MODE” is set to “R-BIT,” “RUNTIME,” the measurement is automatically stopped by satisfying each measurement continuing condition. At this time, RUN LED does not light out until [MENU] is pressed due to the continuous transmission of the test pattern.

- ☰ When the operation is stopped by the use of auto-run function, the transmission of the test pattern is stopped and RUN LED also lights out.

5.2 Data Use

Displays the number of times of measurement at the unit time. (Only at REPEAT measurement)

Name	Description	Measured Range	Note
Savail	Effective period after synchronization is first established	0~9999999(sec)	1, 2
R-Bit	Number of received bits while synchronization is maintained	0~9999999~9.99E9	1
E-Bit	Number of bit errors occurred	0~9999999~9.99E9	
Bit-ER	Bit error rate	0.00E-0~9.99E-9	
LOSS	Number of deviations from synchronization	0~9999	3
R-Blk	Number of received blocks while synchronization is maintained	0~9999999~9.99E9	4
E-Blk	Number of blocks which included bit errors	0~9999999~9.99E9	4
Blk-ER	Block error rate	0.00E-0~9.99E-9	4
E-Sec	Time when bit errors were detected during Savail	0~9999	
%E.F.S	Error-free seconds (%)	0.000~100.000(%)	5

1. Establishment of synchronization : Success in receiving 32 consecutive bits of normal data
2. Valid time: It counts the time as valid time in which bit error rate is under 0.1% for 1 second. When the time continued more than 10 seconds in which bit error rate is 0.1% or more, the 10 seconds are not counted as valid time. In this case, after 10 seconds passes in which bit error rate is under 0.1%, it restart to count including the 10 seconds.
3. SYNC LOSS : Occurrence of at least 200 error bits among 512 consecutive bits
4. 1 BLOCK LENGTH : Number of bits in one cycle of test pattern
5. %E.F.S:
$$\frac{(\text{Savail})-(\text{E-Sec})}{(\text{Savail})}$$

- ◆ "REPEAT" mode allows you to scroll the several measured data by [▲], [▼].

Also, after pressing [F] to input the number key, the specific data can be displayed by pressing [ENTER].

- ◆ When selecting REPEAT, it is possible to print continuously in the table format and to capture data to the PC in TEXT data format. One measurement is shown by one line. From the data displayed on the present screen, the data of every 60 lines per specific 1 page is printed. Printed items will be different in every measured data.

6.1 Trigger Function (TRIGGER)

Trigger Function is to start a specific action upon occurrence of a specific event as the trigger. A perplexing flow of data which is not easy to be analyzed. In the normal monitor operation, is analyzed on the basis of occurrence of the specific event.

Setting



To select "TRIGGER," press [2] in the top menu ([MENU]).



Up to four triggers can be set. FACTOR and ACTION may be set for each trigger independently. Each trigger can be set either to be enabled or disabled.

Setting a trigger enable/disable

Press [SHIFT] + [0] to [3](number for trigger) for changes of setting.

e.g. Set trigger No.0 enable by pressing [SHIFT] + [0] and trigger No.2 by pressing [SHIFT] + [2].





TRIGGER
 "☑" ENABLE
 "☐" DISABLE

Enable trigger (☑) with lower number will act first.


Set FACTOR

Press [0] to [3] key corresponding to the desired factor, or move the "➡" mark by the cursor keys ([▲], [▼]) and press [ENTER]. Then, the setting screen will be displayed.



Set ACTION

Press [4] to [7] key corresponding to the desired action, or move the "➡" mark by the cursor keys ([▲], [▼], [▲], [▲]) and press [ENTER]. Then, the setting screen will be displayed.



Trigger Output

When any of the trigger conditions which is set for FACTOR is satisfied, output a pulse for about 1 second from the external signal OT1 terminal.

If you wish to output a pulse only when satisfying a specific trigger condition, use "TRG OT2".

When new triggers occur during the trigger pulse output, the signal level will be HIGH level after approximately 1ms from the last trigger.



■ ERROR

<pre> 4 TRIGGER 0 FACTOR : ERROR PRTY/MP : ON FRAMING : ON BCC : ON BREAK : ON </pre>	<pre> *SELECT* 0: ERROR 1: CHARACTER 2: LINE 3: TM/CT MAT 4: IDLE TIME </pre>
---	---

“ACTION” takes place by the generation of an error.

PRTY/MP and BCC are effective only when “NONE” has not been selected in the configuration([MENU],[0]).

PRTY/MP	Parity error or MP bit =1
FRAMING	Framing error
BCC	Block check code error
BREAK	Break

■ CHARACTER

<pre> 4 TRIGGER 0 FACTOR : CHARACTR CHAR SD : 414243 RD : MASK W0 : ***** W1 : ***** W2 : ***** </pre>	<pre> *INPUT* SET 0~8 CHARACTER (00~Ff, * ~ W0~#2) (HEX CODE) W0~#2=SHIFT+0~2 </pre>
--	--

“ACTION” takes place by the generation of a specific characters. Up to 8 characters can be set for each of SD or RD sides separately. X(Don’t care), bit mask (up to 3 kinds) and flag (enter [SHIFT]+[F]) of SDLC HDLC can also be set.

 Setting the RD side will be disabled if both SD and RD will be set by character trigger.

■ LINE

<pre> 4 TRIGGER 0 FACTOR : LINE RS CS DR CD ER SW CI EX C1 * * * * * * * </pre>	<pre> *INPUT* SET PATTERN (0, 1, *) </pre>
---	--

“ACTION” takes place by a status of each signal line. Set the conditions with 1(H), 0(L) or X (Don’t care) for the 7 lines: RS, CS, DR, CD, ER, CI and EX. The status judgment on 1, or 0 is displayed in the same way as the line state display.

 Two or more of 1/ 0 are set in the setting of LINE, ACTION is taken according to the agreement of all the conditions (AND conditions). ACTION is taken when the state changes from the condition disagreement to the condition agreement.

 “SQ” is only for interchanging with former models.

 EX corresponds with the external input (EXT.IN). EXT.IN is pulled up with DC5V and 10KΩ.

■ TM/CT MAT

<pre> 4 TRIGGER 0 FACTOR : TM/CT POINT : TM0 </pre>	<pre> *SELECT* 0: ERROR 1: CHARACTER 2: LINE 3: TM/CT MAT 4: IDLE TIME </pre>
---	---

“ACTION” takes place when the timer or the counter reaches a preset value. Specify which timer (TM 0, TM 1) or counter (CT 0, CT 1) is to be used.

 6.2 Timer/Counter Function

■ IDLE TIME

<pre> 4 TRIGGER 0 FACTOR : IDLE TM IDLE TM : 0 </pre>	<pre> *SELECT* 0: ERROR 1: CHARACTER 2: LINE 3: TM/CT MAT 4: IDLE TIME </pre>
---	---

“ACTION” takes place when the idle time reaches a preset value.

■ BUZZER

TRIGGER 0	*SELECT*
ACTION :BUZZER	0:BUZZER
	1:STOP
	2:SAVE
	3:TIMER
	4:COUNTER
	5:TRIG SW
	6:SEND 7:OT2

Buzzer sounds for about 0.3 seconds.

■ STOP

TRIGGER 0	*SELECT*
ACTION :STOP	0:BUZZER
OFFSET :QUICK	1:STOP
	2:SAVE
	3:TIMER
	4:COUNTER
	5:TRIG SW
	6:SEND 7:OT2

Measurement stops automatically. Delay time from the occurrence of the trigger to the stop of measurement can be set with OFFSET.

- QUICK Stops the measurement immediately as trigger occurs.
- BEFORE Stops the measurement after taking in a large amount of data which exists before the trigger.
- CENTER Stops the measurement so that the same amount of data is taken in before and after the trigger.
- AFTER Stops the measurement after taking in a large amount of data which exists after the trigger.

■ SAVE

TRIGGER 0	*SELECT*
ACTION :SAVE	0:BUZZER
OFFSET- : 0	1:STOP
OFFSET+ : 0	2:SAVE
	3:TIMER
	4:COUNTER
	5:TRIG SW
	6:SEND 7:OT2

Save some data which exists before/after the trigger satisfaction. Set the amount of data (max.9999) to save by setting OFFSET (+)(-). OFFSET + means after the trigger and OFFSET - means before the trigger.

- It saves as a file when capturing data set in OFFSET (+)(-).
- "SAVE" action does not work while processing previous "SAVE" function.
- "SAVE" process will not be completed if stopping the measurement.
- It does not write when storage device is full.

DIRECTORY	REMAIN	487MB
TGSAVE00.DT	1432	08-10-01 10:54:44
TGSAVE01.DT	1432	08-10-01 10:55:34
TGSAVE02.DT	1432	08-10-01 10:56:24
TGSAVE03.DT	1432	08-10-01 10:57:14
SELECT FUNCTION	PUSH PAGE DOWN	
0:SAVE	1:LOAD	2:DELETE

The name of trigger saved file is "TGSAVEnn.DT".

- "nn" means number which is added automatically from 00 to 99 and is in the order of trigger saved.
- If the file name is over 99 in "SAVE" ACTION, the name is overwritten as 00.
- When you press [RUN], the file name will start from 00.

Display by [LOAD/SAVE] after the measure

■ TIMER

TRIGGER 0	*SELECT*
ACTION :TIMER	0:BUZZER
TM No :TM0	1:STOP
:START	2:SAVE
	3:TIMER
	4:COUNTER
	5:TRIG SW
	6:SEND 7:OT2

Control the timer.

Specify the timer number (TM0 or TM1) to be controlled and the type of control (START, STOP, RESTART).

6.2 Timer / Counter Function

■ COUNTER

TRIGGER 0	*SELECT*
ACTION :COUNTER	0:BUZZER
CT No :CT0	1:STOP
:INCREMENT	2:SAVE
	3:TIMER
	4:COUNTER
	5:TRIG SW
	6:SEND 7:OT2

Control the counter.

Specify the counter number (CT0 or CT1) to be controlled and the type of control (INCREMENT: +1 , CLEAR: 0).

6.2 Timer / Counter Function

■ TRIG SW

TRIGGER 0	*SELECT*
ACTION :TRIG SW	0:BUZZER
TRIG No :TRIGGER0	1:STOP
:ENABLE	2:SAVE
	3:TIMER
	4:COUNTER
	5:TRIG SW
	6:SEND 7:OT2

Set the state of another trigger when one trigger is satisfied.

- DISABLE → (ineffective)
- ENABLE → (effective)
- CHANGE → (switch "Disable"->"Enable" and vice versa)

■ SEND

TRIGGER 0	*SELECT*
ACTION :SEND	0:BUZZER
TABLE No:00	1:STOP
RESPONSE : 0	2:SAVE
	3:TIMER
	4:COUNTER
	5:TRIG SW
	6:SEND 7:OT2

Send the registered data.

Data for sending must be set in the data table beforehand. Delay from the occurrence of a trigger before the start of data transmission (response time) can be set in the range of 0 to 99.999 sec.

- "SEND" ACTION does not operate in the MONITOR but operates only in the SIMULATION "MANUAL" mode.

■ TRG OT2

TRIGGER 0	*SELECT*
ACTION :OT2	0:BUZZER
	1:STOP
	2:SAVE
	3:TIMER
	4:COUNTER
	5:TRIG SW
	6:SEND 7:OT2

The pulse is output from the external signal OT2 port.

6.2 Timer/Counter Function(TM/CT)

The Timer/Counter Function, in conjunction with the trigger function or the simulation "PROGRAM" mode, measures the elapsed time since a specific factor occurred and counts the number of occurrences of a specific factor.

Use "Timer" 0, 1 when measuring the elapsed time since a specific factor occurred.

Use "Counter" 0, 1 when counting the number of occurrences of a specific factor.

Use "Counter" 2, 3 when counting the total number of transmission/ reception of data (max. 4294967295).

Setting

◀TIMER/COUNTER▶		* INPUT*
TIMER 0:	1	SET TIMER0
SCALE:	* 10ms	
TIMER 1:	1	
SCALE:	* 10ms	(1-999999)
COUNTER0:	1	(DECIMAL)
COUNTER1:	1	

To select "TRIGGER," press [2] in the top menu ([MENU]). Then press [F] and select "TIMER/COUNTER SETTING."

Move "←" and set each Timer/ Counter (1-999999) and resolution (100ms, 10ms, 1ms)

Timer Operation

1. Clears the timer to 0 and stops as soon as measurement starts.
2. Starts(0:START), stops(1:STOP) or restarts(2:RESTART) by the control information of trigger.
3. When the number on "SET" and "NOW" in Timer 0, 1 is matched, that information is sent to the trigger.
4. Restarts counting from 0, in the case of an overflow of NOW.
5. Timer will stop at the time of measurement stops.

Counter Operation

- General purpose counter (COUNTER0,1)
 1. Clears the counter to 0 as soon as measurement starts.
 2. Is incremented or cleared as a result of the control condition of the trigger.
 3. When the number on "SET" and "NOW" in Counter 0, 1 is matched, that information is sent to the trigger.
 4. Restarts counting from 0, in the case of an overflow of NOW.
- Transmission/ receptio data counter (COUNTER 2,3)
 1. Clears the counter to 0 as soon as measurement starts.
 2. Increments by 1 when data from SD or RD is received. (Max. 4294967295)

Display

◀ TIME/COUNT ▶		SET		NOW
TIMER 0	[E]	[1]	[E]	[0]
TIMER 1	[E]	[1]	[E]	[0]
COUNTER0	[E]	[1]	[E]	[0]
COUNTER1	[E]	[1]	[E]	[0]
COUNTER2		SD	[E]	[0]
COUNTER3		RD	[E]	[0]

Preset and current values of the timers and counters can be checked by pressing [TIME/COUNT] even during measurement.

6.3 Timing Waveform Measurement Function(WAVE MON)

The function is to measure the timing of data as a logic analyzer through a communication channel.
Timing of communication line is displayed by waveform in time resolution of max.50n sec.

Setting

WAVE MONITOR MONITOR : ON SAMPLING CLOCK : 50μs TRIGGER POSITION : CENTER <small>PUSH PAGE DOWN</small>	*SELECT* MONITOR MODE 0:OFF 1:ON
--	--

To select "WAVE MON," press [4] in the top menu ([MENU]).

Set timing waveform measurement by moving the "←" mark with a cursor key.

SAMPLING CLOCK

WAVE MONITOR MONITOR : ON SAMPLING CLOCK : 10μs TRIGGER POSITION : CENTER <small>PUSH PAGE DOWN</small>	*SELECT* 0:50n 7:10μ 1:100n 8:20μ 2:200n 9:50μ 3:500n A:100μ 4:1μ B:200μ 5:2μ C:500μ 6:5μ D:1m
--	--


Set SAMPLING CLOCK by [0] to [D].

TRIGGER POSITION

WAVE MONITOR MONITOR : ON SAMPLING CLOCK : 10μs TRIGGER POSITION : CENTER <small>PUSH PAGE DOWN</small>	*SELECT* 0:BEFORE 1:CENTER 2:AFTER
--	--

Set TRIGGER POSITION in the timing waveform measurement sampling memory (for 2K sampling).

- BEFORE: Stops the measurement after taking in a large amount of data before the trigger.
- CENTER: Stops the measurement so that the same amount of data is taken in before and after the trigger.
- AFTER : Stops the measurement after taking in a large amount of data after the trigger.




TRIGGER CONDITION

WAVE MONITOR (RS232C) [***↑***] [***] [***] [***] [***] [***] [***] [***] SRRR DECC SSRE DDSS RRD1 11TX 12 T <small>PUSH PAGE UP</small>	*INPUT* TRIGGER CONDITION SET (0, 1, *, ↓, ↑) ↓ : SHIF+0 ↑ : SHIF+1
---	---

Set the line state to be a trigger condition by pressing [PAGE DOWN].


- [0] : 0
- [1] : 1
- [X] : Option ("*"don't care)
- [SHIFT]+[0]: Falling edge
- [SHIFT]+[1]: Rising edge

- ☒ Be sure to set edge (↑) (↓) for trigger condition.
- ☒ "EXT" means the external input terminal "INI".




Operation


1. Press [RUN] and start the ordinary measuring and the waveform measuring at the same time.
2. "WAVE-MON END" will be displayed on the right below of the screen when the trigger satisfied and waveform measuring ends.
3. Press [STOP] to stop measurement.



Press [TIME / COUNT] for a few times to change the screen to the timing waveform.





Display in the screen can be scrolled right and left by pressing [◀] or [▶].
Paging of display in the screen is possible by pressing [PAGE UP] or [PAGE DOWN].



[ZOOM/CODE]: Enlarged display (zooming in),
[SHIFT]+[ZOOM/CODE]: Reduced display (zooming out)
Enlarges and reduces one by one in the following order.


1/64 ↔ 1/32 ↔ 1/16 ↔ 1/8 ↔ 1/4 ↔ 1/2 ↔ 1 ↔ 2 ↔ 4 ↔ 8 ↔ 16

- Display order of signal line can be changed.




[▲],[▼] : Selection of signal line [SHIFT]+[▲] , [SHIFT]+[▼]: Movement of selected signal line
☰ To display the signal lines not displayed, press [▲], [▼].

- Measurement time for two points can be performed.
e.g. Measurement from falling edge of CS to start bit of SD. (trigger condition CS↓)




Move the cursor to falling position of CS.
Move the cursor to the right with [3] or [SHIFT]+[▶].
Move the cursor to the left with [2] or [SHIFT] + [◀].



Fix the cursor by pressing [ENTER].


☰ Line state of cursor position will be displayed.



Move the cursor to SD of falling with [3] or [SHIFT]+[▶].

☰ The time difference is 160 us..

■ Timing search



The search mode will be set after pressing [FIND].

Move the “■” mark with [▲], [▼].

Input the conditions.

- 0 : [0]
- 1 : [1]
- ↑ : [SHIFT]+[1] (rising edge)
- ↓ : [SHIFT]+[0] (falling edge)
- * : [END/X] (don't care)


Search by [◀], [▶].

The cursor moves to the position where the condition is consisted.

6.4 Communication Condition Auto Setting Function(AUTO CONF)

AUTO-configuration is a function that automatically determines the conditions of communication through a communication channel.(Only for MONITOR/ONLINE)

Setting



To select “AUTO CONF;” press [6] in the top menu screen ([MENU]).

Move “◀” mark with the cursor key and set the process after the auto -configuration..

[0]:The operation stops and displays the communication conditions which have been determined.

The configuration settings will not be renewed by this operation.

[1]:The monitor operation starts automatically after replacing the configuration settings with the determined settings.

Action

- [RUN] Starts an analysis to determine the monitor conditions.
 - The analysis continues until all the necessary items to be set are determined. “****” on the screen indicates that the analysis is in progress, and “???” indicates that is in standby ready to run again.
- [STOP] Interrupts the process of analysis.
 - The analyzer returns to the auto-configuration setting screen regardless of the setting. (The configuration is not renewed.)

Upon the end of the analysis, the results of the analysis will be displayed or the monitor operation will start depending on the setting in step.

If “STOP” is selected in step, the following key operations are available.

[STOP] :Displays the auto-configuration screen.

[RUN] :Renews the configuration according to the result of the analysis.

<Conditions required for auto -configuration of communication conditions>

- ◆ A bit pattern "101" or "010" must be on the data lines.
- ◆ Various data must be sent through the communication channel.
 - Over 115.2Kbps transmission rate can not be analyzed.







Attention

Auto configuration is not 100% correct because the communication conditions of target devices vary. Please use the result as one example of setting.

6.5 Logging Function for a Long Time

Data in capture memory while monitoring can be saved automatically to the optional storage device as the appointed size of measurement log file. The file can be checked by file management function of the analyzer or optional PC link software. It is useful for rare network trouble of unknown cause by recording communication state for a long time can be stored.

Setting



To select "CONDITION," press [3] in the top menu.

Select [0]"BUFFER SELECT."

Move " ← " by pressing [▼]. Set "FULL STOP" to "OFF", and set "AUTOSAVE" to "ON", then press [PAGE DOWN].

- Be sure that the measurement will stop when the capture buffer is full of data if "FULL STOP" is set to "ON".

MAXFILES : sets the maximum number of files to save.

- It may not be able to save data up to the maximum number of files because of the limitation of media even if the memory card has remaining capacity.

FILESIZE : specifies the file size to save.

- "BUF" stands for the capture memory size.
- When you set the size more than the capture memory, it cannot be loaded to the analyzer. Use another tools like the PC link soft.

APPEND : sets how to use the existing file when saving new data.

- OFF : When starting measurement, the existing auto-saved file is deleted.
- ON : When starting measurement, the existing auto saved file is saved without deleting.

Auto Save

■ Preparation

Insert a SD card or a USB flash memory to the analyzer. <Continuous recording time reference>

Communication Speed(*1)	Storage device (8 GB)	Storage device (16 GB)
9600bps	about 480 hours	about 960 hours
1Mbps	about 5 hours	about 10 hours

*1 : In the case that the communication on full duplex where 1KB data is being transmitted per 1ms.

- Only the SD card which LINEEYE sells as its option is guaranteed.
- The analyzer uses 4byte for one sampling of communication data.
- Make sure that you should let the battery fully charged and use AC adaptor before starting long time measurement.

Attention

When the power of the analyzer is turned off during the long time measurement, not only auto -save files but also the storage device may be unable to be accessed. So do not turn off the power during measurement.

■ Measurement

Press [RUN] to start measuring on the action mode previously selected. The analyzer makes files everytime when amount of "FILE SIZE" in "BUFFER SELECT" is saved to the capture memory. The filename "#XXXXXXXX.DT"(XXXXXXXX is the number which starts from 0000000) is saved to the storage device. When the number of the auto-saved files is over the max of the setting, or free space of the memory card is not enough, the old ones for the those files are deleted from the oldest file.


- When the memory card includes the auto-saved files, the message box appears at the time of starting the new measurement. If you like to delete the old files, press again to start measurement. If you would like to keep them, press , and save them to your PC or another storage device.
- Up to about 1Mbps makes the AUTOSAVE function operate without lack of capturing data. During measurement if lack of data occurs, the lack number is displayed at the bottom line in the screen. After measurement, when you display the auto-saved data on the screen, the "LD" shows the place of lacking data in the screen.

Measuring Screen



The display of lacking data

Data Display



- ☞ Before it reaches the specified file number but run out the storage device, it deletes the oldest file and keeps measuring.
- ☞ Timing waveform is not recorded in the automatic save file.
- ☞ Do not turn off the power before it finish saving the all file after you push [STOP].

■ How to check the automatically saved data via Wi-Fi

Using a PC software "LE file downloader" you can download to your PC via Wi-Fi the measurement log file (#XXXXXXXX.DT) saved in the SD card or USB memory without stopping the measurement.

You can download the software from LINEEYE website. Please refer to the manual attached to the software for the detail.

- ☞ This function is valid by the firmware V1.06 or later.

6.6 Automatic Start and Stop Function(AUTO RUN)

The AUTO RUN function enables you to start and stop a measurement at the specified time.

It is useful when you monitor at the specific time only.

← AUTO RUN	▶	*SELECT*
DATE: 11/01	10:32	0 MONTHLY
MODE: DAILY		1 DAILY
RUN TIME: ON	** 09:30	2 HOURLY
STOP TIME: ON	** 18:00	
P-ON RUN: ON		

Ex.)

Starts measuring at 9:30 to 18:00 every day

To display the "CONDITION," press [3] on the top menu screen ([MENU]). And then select [4] and set "AUTO RUN."

- MODE : Selects MONTHLY, DAILY and HOURLY.
- RUN TIME : Selects date, minute, and hour to start measurement following the MODE setting.
- STOPTIME : Selects date, minute, and hour to stop measurement following the MODE setting.

Once you press [RUN], it will remain standby until preset time.

← AUTO RUN	▶	*SELECT*
DATE: 11/01	10:32	POWER-ON RUN
MODE: DAILY		0 OFF
RUN TIME: ON	** 09:30	1 ON
STOP TIME: ON	** 18:00	
P-ON RUN: ON		

- P-ON RUN : When in the ON setting, measurement starts in ten seconds after the power on.

6.7 Display Screen Switching Function



Display Switch

[DISPLAY MODE] display screen can be changed.

ASYNC → Data display → Line state display(*1) → BSC translation display(*1) → Display per the frame(*2)

ASYNC(PPP) → Data display → Line state display(*1) → PPP translation display → PPP frame display

*1: It will be displayed when selecting "CONDITION" -> [1]"RECORD & DISPLAY CONTROL" -> "LINE REC" to "BSC".

*2: It will be displayed when the item of "TM STAMP" except "OFF" is selected at "RECORD & DISPLAY CONTROL" in "CONDITION" menu.



Display Code Change

[HEX] The display codes can be switched to HEX.

To return to the former code, toggle this again.

[ZOOM/CODE] The display code can be changed in order.

→ ASCII → EBCDIC → EBCDIK → JIS7 → JIS8 → HEX → EBCD → Transcode → IPARS → Baudot

Block check codes and the like are displayed in special characters.



Scroll

[←],[▲],[PAGE UP] Scrolls/Paging to forward (older data).

[→],[▼],[PAGE DOWN] Scrolls/Paging to backward (later data).



Jump

[TOP/DEL] :Jumps to the front (1 position : oldest data) of data which was saved in capture buffer.

[END/X] :Jumps to the back (the last position : latest data) of data which was saved in capture buffer.

[0]-[9],[ENTER] :Jumps specified position.

The last page is displayed if you input larger position number than measured position.

6.8 Translation Function

Display Screen (Translation)

■ BSC Translation Display

Only the communication control characters of the BSC procedure are displayed while decoding the transmitted/received data.

```

+TMSP+TMSP+TMSP+TMSP+TMSP+
+133105+133108+133125+ErG+133115+133118+
+TMSP+TMSP+TMSP+TMSP+TMSP+
+133121+133124+133126+133130+ErG+133132+
+TMSP+TMSP+TMSP+TMSP+TMSP+
+133135+133138+133140+133141+ErG+133145+
+-----+
|      | 0  BSC      | 9600/ 9600 |
+-----+
  
```

Press [3] on the top menu screen ([MENU]) and select "CONDITION." Then select and set [1]"RECORD&DISPLAY CONTROL."Set "ON" for "BSC."

To switch the screen for translation display, press [DISPLAY MODE].

- ☐ Screen scrolling and jumping during the BSC translation is done by translating the data of one-screen after scroll- paging the normal data display screen. Therefore, if the one-screen data in the screen after paging includes only text characters to be omitted, the translation display does not change by performing one paging operation.
- ☐ Code systems can not be changed with [ZOOM/CODE] or [HEX].

■ Frame display screen of ASYNC

Displays the data of ASYNC protocol per the frame.

It is valid only when "PROTOCOL" is "ASYNC" and the time stamp function is enabled.

After measuring the data, the frame display screen can be shown by pressing [DISPLAY MODE] several times.

- ☐ It will be displayed when the item of "TM STAMP" except "OFF" is selected at "RECORD & DISPLAY CONTROL" of "CONDITON" menu.
- ☐ When it is ASYNC, frames are separated by the idle time more than that of set in the "FRM TIME" item of "CONFIG" or by the character detection set in "FRM END" item, Please set these properly.

Normal data display screen

```

+TMSPATc&+f+TMSP+TMSP+TMSPAT&F+TMSP+
+135759+135801+OKc&+f+135803+135803+
+SP+TMSPATE0V1S75=0S95=45+&C1&D2+
+300+OKc&+f+135808+
+&C1&D2+TMSP+TMSP+TMSPATc&+f+
+135811+135816+
+-----+
|      | 0  ASCII      | 9600/ 9600 |
+-----+
  
```

Display per a frame (Normal time stamp)

```

- TM - DATA -----
+135759 ATc&+f
+135801 OKc&+f
+135803 AT&F+TMSP+
+135806 OKc&+f
+135808 ATE0V1S75=0S95=45+&C1&D2
+135811 TIMEOUTc&+f
+-----+
|      | 0  ASCII      | 9600/ 9600 |
+-----+
  
```

The screen can be changed to the frame data display screen by pressing [DISPLAY MODE] several times.

- ☐ In this screen, the display code of the data can be changed by pressing [ZOOM/CODE] or [HEX/CHAR].However, the data that are displayed in special characters like BCC or the data of which the error was detected, are displayed as normal data.(HEX selected by [CODE] key is same as HEX by [HEX] key.)

Display per a frame (Display of difference between two time stamps)


```

-dt- DATA -----
+000002 ATc&+f
+000002 OKc&+f
+000002 AT&F+TMSP+
+000002 OKc&+f
+000002 ATE0V1S75=0S95=45+&C1&D2
+000002 TIMEOUTc&+f
+-----+
|      | 0  ASCII      | 9600/ 9600 |
+-----+
  
```

After the measurement, Normal time stamp can be changed to Difference between time stamps by [SHIFT]+[TIME/COUNT].

■ PPP Translation

The protocol value, code in LCP packet, identifier and other information of the frame are translated and displayed.



This screen is displayed only when “PROTOCOL” has been set to “PPP.”


Displaying words & phrases	Meaning
“→”line	Indicates that the frame is on the SD side.
“←”line	Indicates that the frame is on the RD side.
TM	Shows the time when the frame was received. ^{(*)1} ^{(*)2}
PROTOCOL	Translates and displays the protocol value.
CODE	Translates and displays the code field value.
ID	Displays the value of identifier field as decimal figure.
FC	Displays the results of frame check.

*1 Shows unless “TM STAMP” is in the OFF setting at “RECORD&DISPLAY CONTROL” of the “CONDITION” menu.

*2 On the time display, by pressing [SHIFT] + [TIME/COUNT] the normal display can be changed to the difference display.

◆ The analyzer translates all bits of ACCM as 0.

(Example) All bits of ACCM are ON (1) between communications equipment.



It is possible to receive and display all data being translated.

When data (7E FF 03 00 21 31 32 11 33 34 7E) is sent on the circuit as shown above, only 11 from received data is not processed as recognizable data; However, the analyzer translate 11 as data.

■ PPP Frame Display

The time stamp on reception of the frame and the contents of the data are displayed. PPP frame display makes it to check overall data exchange and communication.



This screen is displayed only when “PROTOCOL” has been set to “PPP.”

Displaying words & phrases	Meaning
“→”line	Indicates that the frame is on the SD side.
“←”line	Indicates that the frame is on the RD side.
TM	Shows the time when the frame was received. ^{(*)1} ^{(*)2}
DATA	Displays the data.

*1 Shows unless “TM STAMP” is in the OFF setting at “RECORD&DISPLAY CONTROL” of the “CONDITION” menu.

*2 By pressing [SHIFT] + [TIME/COUNT], the normal time stamp display can be changed to the difference between time stamps display.

6.9 Retrieval Function

The retrieval function enables you to find specific data among the vast amount of data recorded in the capture memory during monitoring. It also enables you to count the number which satisfies a particular condition.

Setting

```

┌ FIND SETUP ─┐
FACTOR : TRIGGER  ◀ *SELECT*
└──────────┘
0 TRIGGER
1 ERROR
2 CHARACTER
3 IDLE TIME
4 TM STAMP

ACTION : DISPLAY
    
```

To display the retrieval condition setting screen, press [SHIFT]+[FIND] in the display mode.

Move "◀" by [▲], [▼] and set retrieval Factor and Action.

Setting of FACTOR

```

┌ FIND SETUP ─┐
FACTOR : TRIGGER  ◀ *SELECT*
└──────────┘
0 TRIGGER
1 ERROR
2 CHARACTER
3 IDLE TIME
4 TM STAMP

ACTION : DISPLAY
    
```

TRIGGER: Data which satisfies the trigger condition (FACTOR) is retrieved.
TRIGGER is not retrieved in the case the trigger condition is "TM/CT"

```

┌ FIND SETUP ─┐
FACTOR : ERROR    ◀ *SELECT*
PRTY/MP : ON
FRAMING : ON
BCC : ON
BREAK : ON
└──────────┘
0 TRIGGER
1 ERROR
2 CHARACTER
3 IDLE TIME
4 TM STAMP

ACTION : DISPLAY
    
```

ERROR: Retrieve errors which are set "ON".
Erro items are same as trigger errors.
PRTY/MP and BCC are enabled only when items except "NONE" have been set in CONFIGURATION.

```

┌ FIND SETUP ─┐
FACTOR : CHARACTER ◀ *INPUT*
CHAR SD : 41243
RD :
MASK W0 : *****
      W1 : *****
      W2 : *****
└──────────┘
SET 0~8 CHARACTER
      (00~FF * * W0~W2)
      (HEX CODE)
W0~W2=SHIFT0~2
      ↑ =SHIFTF

ACTION : DISPLAY
    
```

CHARACTER: Sets character string to be retrieved separately for each of SD and RD sides up to 8 characters.
Don't care (X) and flag ([SHIFT]+[F]) of SDLC HDLC can be set.

```

┌ FIND SETUP ─┐
FACTOR : IDLE TM ◀ *INPUT*
IDLE TM : 0
└──────────┘
SET IDLE TIME
      (0~9999)
      (DECIMAL)

ACTION : DISPLAY
    
```

IDLE TM: Retrieve idle time which is more than preset value.
The setting unit of idle time for retrieval is the same as the unit of idle time for measurement.

```

┌ FIND SETUP ─┐
FACTOR : TM STAMP ◀ *INPUT*
TM STAMP : 08:00:00
└──────────┘
SET TM STAMP
      (0~9:*)
      (DECIMAL)

ACTION : DISPLAY
    
```

TM STMP: Retrieve specified time stamps. Time stamp is possible part of the designate time to be specified as "don't care" with [END/X]. If an upper digit is specified as "don't care" the lower digit is also sought as "don't care."
The unit of retrieval setting of time stamp is done in the format as the time stamp setting unit.

Example of entry	Time to search
15:48:20 (HMS form at)	15hours 48min. 20sec.
07:16:52 (DHM form at)	7th 16hours 52min.
07:1*:** (DHM form at)	7th 10hours 00min. to 7th 19hours 59sec.

ACTION

- [0]:DISPLAY Data which satisfies the retrieval condition is displayed at the top line of the screen.
- [1]:COUNT The count, which is the number of times the retrieval condition was satisfied, is displayed in the function display section.

Retrieve

```

→ IDLE TMSPTHE QUICK BROWN FOX →
← 5251 31182 →
→ JUMPS OVER A LAZY DOG 012345 →
← 5789 IDLE TMSPT 0123456789 ABCD →
← 3265 31456 →
┌ 0 ASCII FIND TRIGGER
    
```

When the setting is finished, press [FIND] to return to the data display screen.

The function display section shows "FIND part a part b."

- Part a: Indicates the direction of retrieval. Switch by [▲], [▼].
"▲"(forward retrieval):Retrieves previous (older) data, including the data display screen.
"▼"(backward retrieval):Retrieves rearward (new) data, including the data display screen.
- Part b: The setting contents of "FACTOR." Switch by [▲], [▼].

TRIGGER ↔ ERROR ↔ CHARACTER ↔ IDLE TM ↔ TM STAMP

To start for retrieval, press [ENTER] .

On "DISPLAY" selected at "ACTION":

- If data which satisfies the retrieval condition is found, the data is displayed at the top of the screen.
- If data which satisfies the retrieval condition is not found, the message "NOT FOUND" is displayed.
- Then, the retrieval mode will stop.

On "COUNT" selected at "ACTION":

The number of data pieces which satisfy the retrieval condition are counted. When all the data have been scanned, the results of the retrieval are displayed. Then, the retrieval mode will stop.


6.10 Recording Function to Measure Additional Information (Idle Time, Time Stamp etc.)

This section explains the setting of the additional information along with the data transmitted and received during measuring. Measuring and recording are carried out according to the conditions being set before the measurement. After the end of the measurement, the data is also displayed according to the initial setting, regardless of the conditions being set afterwards.

Idle Time Display Function

Idle time which is in mark state (not sending data) is measured.

- At first, to select "CONDITION," press [3] on the top menu screen ([MENU]). Next, to select "RECORD&DISPLAY CONTROL," press [1]. Then, move the " ← " mark to "IDLE TM." Set "EXTEND : ON" to have the extended time stamp.



Indicates that there was an idle time of 300 to 309ms. (*In the case of Unit: 10ms)


Item	Description	Range of Value
OFF	The idle time will not be recorded	
100ms	The idle time will be recorded in 100msec (time resolution).	0 to 999.9sec
10ms	The idle time will be recorded in 10msec (time resolution).	0 to 99.99sec
1ms	The idle time will be recorded in 1msec (time resolution).	0 to 9.999sec

- In the case of low channel speed (9600 bps or below), there may be differences between the real idle time and the displayed idle time.
- "OVER" is displayed when the range of value is exceeded.

Time Stamp Function

This function can record the time, when the top character of each frame transmitted through on the communication channel is received, into the buffer memory, and can display it.

- At first, to select "CONDITION," press [3] on the top menu screen ([MENU]). Next, to select "RECORD&DISPLAY CONTROL," press [1]. Then, move the " ← " mark to "TM STAMP." Set "EXTEND : ON" to have the extended time stamp.



Indicates that last data was received at 48min 32.86sec. (*In the case MS10m is set.)

- The expansion of time stamp is valid by the firmware V1.06 or later.

Item	Description	
	EXTEND=OFF	EXTEND=ON
OFF	The time stamp is inactive.	
DHM	The time when a frame was received is set in "day, hour ,minute."	The time when a frame was received is set in "year, month, day, hour, minute."
HMS	The time when a frame was received is set in "hour, minute , second."	The time when a frame was received is set in "month, day, hour, minute , second."
MS10m	The time when a frame was receive is set in "minute , second , 10m s ."	The time when a frame was receive is set in "day, hour, minute , second , 10m s ."

Line State Display Function

The logical states (timing form) of control lines and the data of SD/RD (one line for each) are displayed simultaneously.

- At first, to select "CONDITION," press [3] on the top menu screen ([MENU]). Next, to select "RECORD&DISPLAY CONTROL," press [1]. Then, move the "◀" mark to "LINE REC" and set "LINE REC" to "ON".

◀ REC & DISP ▶	*SELECT*
IDLE_TM : *1ms	0:OFF
TM_STAMP:HMS	1:ON
EXTEND:ON	
LINE_REC:OFF	
LINEDISP:RSCSDER	
BSC:OFF	


- Select "LINEDISP" with [▼], and then select the line state on the line state display.

◀ REC & DISP ▶	*SELECT*
IDLE_TM : *1ms	0:RS 3:RD 6:CI
TM_STAMP:HMS	1:CS 4:ER 7:EN
EXTEND:ON	2:OR 5:SR
LINE_REC:ON	
LINEDISP:RSCSDER	◀ SELECT
BSC:OFF	4 LINES

Four lines can be selected for the line state display.

Enter the corresponding number to select the line state.

- Press [DISPLAY MODE] to switch the screen for line state display.



Display line state which makes LED lights on as "H", and which makes LED lights out as "L".

- “EX” displays the logic state of TTL level which is input from external signal input/ output terminal, "TRIGGER IN1".
- “SQ” is for the future use and will not be displayed.

Chapter 7 Data Usage Chapter

The printing function enables it to continuously printout data to a Printer/SD card/USB flash in various formats. The hard copy printing of the screen image can also be obtained.



Connection to a Printer

- Connect AUX(RS-232C) port of the Analyzer and the printer in the appropriate RS-232C cable.
 Use the optional cable LE2-8P to use the optional printer "DPU-414".



Setting for Print out

- To select "CONDITION", press [3] on the top menu. To select "PRINT OUT CONDITION" in the setup window, press [2]. Then, move the "←" mark by [▲], [▼] to select each item.

```

< CONDITION >
0 BUFFER SELECT
1 RECORD & DISPLAY CONTROL
* 2 PRINT OUT CONDITION
3 AUX CONDITION
4 AUTO RUN
5 TIME & DATE SET
6 OTHER FUNCTION
    
```

```

< PRINT OUT >
COLUMN : 80
PAGESIZE : MAX
PRINTER : DPU414
OUTPUT : USB
*SELECT*
0 AUX
1 SD-CARD
2 USB-MEMORY
    
```

Item	Description	Setting range
COLUMN	Number of digits per line	40, 80, 136
PAGESIZE	Mode of printing page	MAX : Continuous printing 66 : Feed 6 lines after printing 60 lines
PRINTER	Printer control code(*1)	DPU-414, DPU-411, DPU-412, ESC/P24-81, PC-PR201H
OUTPUT	Place to output the text data	SD : SD card(*2) USB: USB flash memory(*2) AUX : AUX (RS-232C) port
EOF	Adding EOF code (1Ah)	Select when you use RS-232C. OFF : For normal use ON : When capturing data in a PC

*1: It is not necessary to set "PRINT OUT CONDITION" for normal use. To print the screen image, logic analyzer waveform or statistic graphs, set the appropriate items for your printer. To capture the screen image as BMP file using the PC link software, select "DPU-414".

*2: When you print the text data, it automatically names the file "DDHHMMSS.TXT" (DDHHMMSS is the time you make the file). When you print the screen image, logic analyzer waveform or statistic graphs, it does not make the text file automatically.

If you select "OUTPUT" to "AUX", you need to set [3]"AUX CONDITION" at CONDITION menu.

Item	Setting	
SPEED	Speed (bps)	9600, 19200, 38400, 57600, 115200, 230400
CHAR BIT	Data bit length	7 bits, 8 bits
PARITY	Parity bit for AUX	NONE, ODD, EVEN
X-CONT	Xon/Xoff Flow control	OFF : RTS-CTS Flow control only
		ON : Xon/Xoff and RTS-CTS Flow control

- Example of DPU-414 setting

Analyzer setting:

"PRINT OUT CONDITION"; COLUMN : 80, PAGESIZE : MAX, PRINTER : DPU-414, OUTPUT : AUX, EOF : OFF
 "AUX CONDITION"; SPEED : 9600, CHRA BIT : 8, PARITY : NONE, X-CONT : OFF

DPU-414 setting (setting which is different from the factory setting):

"Soft DIP SW1" NO.1 : OFF serial

"Soft DIP SW2" NO.1 : OFF 80 column

"Soft DIP SW3" NO.5-8 : [OFF ON ON ON] 9600bps

For more details, please read the instruction manual of DPU-414,

7.1 Hard Copy Printing

It is possible to print the screen image by DPU-414 or other printers which supports the escape codes for LINEEYE analyzer.


Press [SHIFT]+[PRINT] to output the screen image to the printer via AUX port.

- Select the printer at "PRINTER" in the SYSTEM menu -> "PRINT OUT CONDITION".

7.2 Normal Printing

To print measured data

- Press [DISPLAY MODE] and arrange the data to the format in which you wish to print the data.
- Display the measured data which you wish to start printing on the screen by using the page/scroll operation or the search function.
- Press [PRINT], and the FUNCTION display section will show "PRINT". Enter the range of data to be printed in 5-digits in decimal.



- Enter 99999 in the range of printing if you want to print till the last data.

- Press [STOP] to stop printing data.

- Press [ENTER]. The measured data of the specified number of pages will be printed. The measured data stored in the capture buffer will be printed in the format, which corresponds to the screen display mode.

- If the range of printing is set greater than the measured data size, the operation will stop after printing the last data.
- You can stop printing by pressing [STOP] key. But the data which are already processed will be printed.
- To save in a SD card, insert it to the SD card slot.
- During RUN, printing can not be obtained.

Printing Format For The Measured Data

Data Display Mode

Information of one character of the measured data is printed in two lines in both hexadecimal code form and characters using 4-character space.

<Display>

SX	A	B	EX
----	---	---	----



<Printout>

02	41	42	03
SX	A	B	EX

HEX (hexadecimal)
Character

- In case the character code is not defined or "Δ" (space code), nothing is printed in the character code printout line.
- If there is no data, "-" is printed in the HEX printout line.
- Time information and line state of signal lines will be printed as following.

Idle time [I D L E]	Time stamp [T M S P]	Line state H "11"
[0 0 2 0]	[0 5 1 7 3 5]	L "00"
		H→L "10"
		L→H "01"


- If characters of the measured data have special attribute, symbols as shown below will be printed in the character code printout line.

Display	Meaning
?1	Parity error
?2	Framing error
?3	Parity & framing error
?4	Over run error
??	BCC (error)
{}	BCC (normal)
BB	Break
##	MP bit

◇ Printing Example of WAVE MON

<< Timing List >> 2008-09-17 17:24:54

Position: 3852
 Trigger : 3873 Clock:50ns
 Cursor : 4062 Zoom :x1
 Marker : 3976 C-M :4.30us



◇ Printing Example of BERT

```

*=[LE-1500R]===[2015-03-05 14:33:40]=*
* Model      : LE-1500R      *
* Version    : 1.11         *
* Extension  : Standard     *
* Serial No. : *****     *
* Start time : 2012-05-18 20:54:18 *
* Stop time  : 2012-05-18 20:54:22 *
*-----*
* BERT RESULTS *
* PROTOCOL: ASYNC *
* S-SPEED : 9600 R-SPEED : 9600 *
* CHAR BIT: 8 STOP BIT: 1 *
*-----*

```

DATE-TIME	LOSS	R-BIT	E-BIT	BIT-ER	E-BLK	BLK-ER	E-SEC	%E.F.S
05/18 20:23	3	323888	839	1.97E-3	58	1.13E-2	9	84.746
05/18 20:24	11	413440	2202	5.33E-3	85	1.30E-2	8	86.207
05/18 20:25	1	402734	215	5.34E-4	12	1.88E-3	3	94.915
05/18 20:26	0	460744	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:27	7	273059	1401	5.13E-3	50	1.15E-2	0	100.000
05/18 20:28	1	453660	461	1.02E-3	25	3.47E-3	2	96.610
05/18 20:29	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:30	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:31	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:32	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:33	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:34	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:35	0	460744	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:36	9	406429	1806	4.44E-3	67	1.04E-2	6	89.831
05/18 20:37	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:38	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:39	0	435872	41	9.41E-5	1	1.45E-4	1	98.305
05/18 20:40	3	409525	600	1.47E-3	22	3.38E-3	5	91.228
05/18 20:41	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:42	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:43	6	410937	1200	2.92E-3	43	6.59E-3	7	88.136
05/18 20:44	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:45	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:46	0	460744	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:47	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:48	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:49	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:50	0	460752	0	0.00E+0	0	0.00E+0	0	100.000
05/18 20:51	2	279704	488	1.74E-3	16	3.60E-3	4	93.220
05/18 20:52	0	415749	0	0.00E+0	0	0.00E+0	0	100.000

7.3 Usage on PC

By using PC link software (Light Edition), you can execute real time measurement and convert a captured file into text file.

The Captured data is in unique data form thus you need to convert it to use it on PC.

PC link software “LE-PC300R (Light Edition)”


With this software you can take the monitor data into PC through USB port, AUX port(serial), Wi-Fi, or storage device.

 Wi-Fi function is available only in Japan, USA, Canada, and EU nations where the product is needed to be compliant with RE directive (2014/53/EU).

 When you use USB connection, you need to install the USB driver before the use. The driver is in the Driver folder of attached CD-ROM.

■ Install of PC link software

The Utility folder of attached CD-ROM includes the light edition of the PC link software “LE-PC300R”. Double-click setup.exe in the folder and install it following the install wizard.



■ PC Connection

The Utility folder of attached CD-ROM includes the light edition of LE-PC300R.


Double-click setup.exe in the folder and install it following the install wizard.

 For “how to use” of LE-PC300R (Light Edition), refer to the online help of LE-PC300R.

■ Start/Stop measurement


After finishing configuration of communication condition, click  to display and record the measured data. Click  to stop measurement.

 LE-PC300R (Light Edition) has 10 minutes limitation for measurement time. When you need to measure for more long time please purchase the full edition of LE-PC300R.



■ Text conversion

You can convert the data file which is measured by the analyzer into text file. By clicking  of LE-PC300R, the text conversion window opens. Then select the folder which has the data to be converted and select the data. You can select normal format or translation format for the text conversion. You can also convert it to csv format.



 LE-PC300R (Light Edition) has 3 files limitation (at one time) for the file conversion. When you need to convert many files at one time, please purchase the full edition of LE-PC300R.

■ Save

Click  to save the data which was measured by LE-PC300R.

Chapter 8 Save and Load Data

8.1 Storage Device

- USB flash and SD card (LINEEYE option) are available.

Options: SD-8GX, SD-16GX

Do not eject the storage device while saving, auto saving, and auto backup.

8.2 File Management Function

You can do format (initializing), load (readout), save (storing) and delete (erase) of a storage device.

Directory Display

```

<DIR> DIRECTORY <USB> REMAIN 68MB
TGSAVE33.DT 1480 16-10-28 14:03:08
TGSAVE34.DT 1480 16-10-28 14:03:08
#000005.DT 61M 16-10-31 18:45:34
#000006.DT 69M 16-11-01 9:38:06
SELECT FUNCTION PUSH PAGE UP DOWN
0:SAVE 1:LOAD 2:DELETE
    
```

To display the directory screen, press [LOAD/SAVE] in the top menu ([Menu]). When you insert both USB flash and SD card, directory display can be changed by [LOAD]/[SAVE].

- It will not be displayed while measuring.
- Scroll by [▲], [▼], [PAGE UP], [PAGE DOWN].

If a storage device is not set, the “INSERT MEDIA” message is displayed. Insert a USB flash or SD card.

- The files are as follows.

Extension	Contents
DT	Measured data
SU	Condition for communication measurement (including data tables and simulation programs)

- A file saved by the auto save function is automatically named.#nnnnnnn.DT (n means sequence number from 0).
- A file saved by the trigger save is automatically named. TGSAVEnn.DT (n means sequence number from 0).

6.1 Trigger Function
6.5 Logging Function for a Long Time

Format (Initializing)

- Format message will appear if the storage device needs to be formatted. Or press [SHIFT]+[F] in the directory screen to format the storage device.


```

<DIR> DIRECTORY <USB> REMAIN 68MB
FORMAT ?
[ENTER] : YES [STOP] : NO
PUSH PAGE UP DOWN
    
```

Press [ENTER] to format the SD card.
Press [STOP] to cancel.

- Once you format the storage device, the saved files will be erased and cannot be recovered.
- When you need to format the SD card, format it on your PC by using SDFormaterv4 offered by SD Association.

To display the file save screen, press [0] in the directory screen.



1. Enter the file name. Digits 0-9, letters A-F can be entered with the keys. Press [SHIFT]+[HEX/CHAR] to change to Character/HEX input mode.

2.4 Input Character and Binary Data

2. To select a file, move the “ ← ” mark to “TYPE :”. Specify the range to save the measurement data (. DT).
 ALL : All monitor data in the buffer memory.
 CURRENT- : The specified number of data starting with the page currently on display. (1k each)
3. Press [ENTER] to start saving, after completion of the saving operation, the screen returns to the directory display. If the amounts of data to be saved exceed the remaining capacity of the storage device, the error message is displayed in the last line and the saving operation is interrupted. When this happens, try again after reducing the range of data to be saved or deleting unnecessary files.

⚠ Attention	Do not turn off the power of the analyzer or remove the storage device while saving the data.
----------------	---


Filter



- ◆ To display the filter screen, press [SHIFT]+[FIND]. Then, you can display specific files you wish to check.

TYPE	0 : ALL	All the files
	1 : LINEEYE	All the files saved on analyzers
	2 : SETUP	Setup files
	3 : DATA	Data files (xxxxxxx.DT)
	4 : TGSAVE	Trigger save files (TGSAVEnn.DT)
	5 : AUTOSAVE	Autosave files (#nnnnnnn.DT)
MIN TMSP	0 : OFF	All the files
	1 : ON	Files with the updated date of after the specified date
MAX TMSP	0 : OFF	All the files
	1 : ON	Files with the updated date of before the specified date
- ◆ Pressing [FIND] makes you switch the filter function to valid or invalid. When the file filter is valid, [FILTER ON] appears on the right bottom of the screen.

Load



1. Move the “ ► ” mark to the left side of the file to be loaded with [▲], [▼].
2. Press [1] to display the file loading screen.
3. Press [ENTER] for loading. When [STOP] is pressed, loading can be cancelled.
 - Once loading is executed, communication conditions or data in capture memory are overwritten.
 - LINEEYE analyzers are compatible in measurement data file. Part of files or data saved in higher hierarchy models or new modes, however, may not be available in lower hierarchy models or conventional models.

Specified file deletion



1. Move the “▶” mark with [▲], [▼], to the left side of the file to be deleted.
2. To display the file deleting screen, press [2].
3. Press [ENTER] for deletion. To cancel the deletion, press [STOP].

All files deletion



1. To display the file deleting screen, press [2] in the directory screen. Press [END/X].
2. To delete all the files simultaneously, press [ENTER]. To cancel the deletion, press [STOP].

File Filter Deletion

1. To display the files you wish to delete, set the file filter function valid.
2. Selecting all files deletion makes you delete only files which match the filter conditions.
 - 📖 It is useful to delete the only trigger save files, the files of before the specified date, etc.

To change the file name, load the file and save it with the different name.

There are 14 kinds of error as follows when you use the memory card. If you happen to have an error, check them and must take the suitable steps.



Error Message	Meaning
NO MEDIA	No storage device has been inserted.
ILLEGAL CARD	An unacceptable card for the analyzer has been inserted.
ILLEGAL MBR	Master boot record (MBR) is illegal. MBR was never formatted or is damaged.
UNKNOWN FORMAT	Format style is unknown. It is not formatted or formatted illegally.
ILLEGAL MEDIA	Some illegal media exists in the management area.
DIRECTORY FULL	Capacity of the directory is full.
NOT ENOUGH REMAIN	Not enough remain of capacity in the data area.
ACCESS DENIED	Some illegal access was attempted, such as deletion of read-only files.
FILE EXIST	The same file or sub-directory name is already existed.
DATA ERROR	The file to be loaded contains illegal data. The file is unsupported or damaged.
WRITE PROTECTED	The file cannot be loaded, because selected buffer is write-protected. 2.5 Environmental Setting (Conditions)
BUFFER FULL	Loading of a data file exceeding the capacity of selected buffer has been attempted.
I/O ERROR	Error in hardware occurred during input/output process.
ILLEGAL FILENAME	Useless filename in this analyzer was specified.

9.1 Calculation of Block Check

Block check is calculated as follows:


- ASYNC Transmission

- Start of calculation :When any one of the characters set to “BGN CHAR” is received, calculation will start with the next character.
 - End of calculation :When any one of the characters set to “END CHAR” is received, calculation will finish just after the character.
 - BCC check :When the calculation end character is received after the calculation start character has been received, data next to the calculation end character will be checked as the BCC.
- The ITB code is applied equally to the calculation end character.



- Transparent mode (only for ASYNC)

- If you select “ON” for the “TRANSPRT” setting, the Analyzer will enter the transparent mode and calculate BCC as follows.
 - The character set in the “DLE” setting is handled as the Data Link Escape code.
 - The calculation starts and ends block upon <DLE+calculation start code> and <DLE+calculation end code>, respectively. The calculation end code without DLE is treated as normal character.
 - The DLE code is excluded from the calculation of BCC.
- If two DLE codes appear successively, only the first DLE code will be excluded. The second DLE code will be treated as a normal character and therefore be included in the calculation of BCC.
- ASYNC code without DLE code is considered as normal characters, and ASYNC code with DLE code is excepted from the calculation.



- The block of the calculation starting with the calculation start code without DLE is the same as that when “TRANSPRT” is set to “OFF.”

■ Reference

• LRCcode

- LRC O : Longitudinal parity odd
- LRC E : Longitudinal parity even
(‘LRC E’ is normally used.)

• CRC code generating polynomial

- CRC-6 : $X^6 + X^5 + 1$
- CRC-12 : $X^{12} + X^{11} + X^3 + X^2 + X + 1$
- CRC-16 : $X^{16} + X^{15} + X^2 + 1$
- CRC-ITU-T : $X^{16} + X^{12} + X^5 + 1$

• FCS code generating polynomial

- FCS-16 : $X^{16} + X^{12} + X^5 + 1$
- FCS-32 : $X^{32} + X^{26} + X^{23} + X^{16} + X^{12} + X^{11} + X^{10} + X^8 + X^7 + X^5 + X^4 + X^2 + X + 1$
(All one initial)

9.2 Frame

Definition of 1 frame for each protocol is as follows :

Protocol	Definition of 1 frame
ASYNC	A data string of either idle time (between 1 and 100ms) which is set at "FRM TIME" or character which is set at "FRM END".
PPP	A data string from a flag character to a flag character. Escape code is not decoded.

9.3 Data Code Table

- Blank boxes (non-defined code) appeared in the code tables are displayed in hexadecimal code.
- JIS7 EBCD and Baudot codes, SHIFT IN display and SHIFT OUT display are alternated in accordance to the SI SO data.
- Display is started with the SHIFT IN display, immediately after operating RUN.
- When SI is received first, the SHIFT IN is displayed until the next SO is received.
- When SO is received first, the SHIFT OUT is displayed until the next SI is received.

■ ASCII

	0	1	2	3	4	5	6	7
0	NU	DL	△	0	@	P	`	p
1	SH	D1	!	1	A	Q	a	q
2	SX	D2	”	2	B	R	b	r
3	EX	D3	#	3	C	S	c	s
4	ET	D4	\$	4	D	T	d	t
5	EQ	NK	%	5	E	U	e	u
6	AK	SY	&	6	F	V	f	v
7	BL	EB	’	7	G	W	g	w
8	BS	CN	(8	H	X	h	x
9	HT	EM)	9	I	Y	i	y
A	LF	SB	*	:	J	Z	j	z
B	VT	EC	+	;	K	[k	{
C	FF	FS	,	<	L	\	l	
D	CR	GS	-	=	M]	m	}
E	SO	RS	.	>	N	^	n	~
F	SI	US	/	?	O	_	o	DT

■ EBCDIC

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	NU	DL	DS		△	&	-						{	}	\	0
1	SH	D1	SS				/		a	j	~		A	J		1
2	SX	D2	FS	SY					b	k	s		B	K	S	2
3	EX	D3	WS	IR					c	l	t		C	L	T	3
4	PF	RE	BP	PN					d	m	u		D	M	U	4
5	HT	NL	LF	TN					e	n	v		E	N	V	5
6	LC	BS	EB	NS					f	o	w		F	O	W	6
7	DT	PC	EC	ET					g	p	x		G	P	X	7
8	GE	CN	SA	S2					h	q	y		H	Q	Y	8
9	SI	EM	SE	IT					i	r	z		I	R	Z	9
A	RT	US	SM	RF	¢	!		:								
B	VT	C1	CP	C3	.	\$,	#								
C	FF	IF	MA	D4	<	*	%	@								
D	CR	IG	EQ	NK	()	_	'								
E	SO	RS	AK		+	;	>	=								
F	SI	IB	BL	SB		-	?	^								

■ JIS7(7)

Roman

SHIFT IN

	0	1	2	3	4	5	6	7
0	NU	DL	△	0	@	P	`	p
1	SH	D1	!	1	A	Q	a	q
2	SX	D2	”	2	B	R	b	r
3	EX	D3	#	3	C	S	c	s
4	ET	D4	\$	4	D	T	d	t
5	EQ	NK	%	5	E	U	e	u
6	AK	SY	&	6	F	V	f	v
7	BL	EB	'	7	G	W	g	w
8	BS	CN	(8	H	X	h	x
9	HT	EM)	9	I	Y	i	y
A	LF	SB	*	:	J	Z	j	z
B	VT	EC	+	;	K	[k	{
C	FF	FS	,	<	L	¥	l	
D	CR	GS	-	=	M]	m	}
E	SO	RS	.	>	N	^	n	~
F	SI	US	/	?	O	_	o	DT

• When SI is received first, Roman characters are displayed until the next SO is received.

Kana

SHIFT OUT

	0	1	2	3	4	5
0	NU	DL	△	-	タ	ミ
1	SH	D1	。	ア	チ	ム
2	SX	D2	「	イ	ツ	メ
3	EX	D3	」	ウ	テ	モ
4	ET	D4	、	エ	ト	ヤ
5	EQ	NK	・	オ	ナ	ユ
6	AK	SY	ヲ	カ	ニ	ヨ
7	BL	EB	ァ	キ	ヌ	ラ
8	BS	CN	ィ	ク	ネ	リ
9	HT	EM	ゥ	ケ	ノ	ル
A	LF	SB	ェ	コ	ハ	レ
B	VT	EC	ォ	サ	ヒ	ロ
C	FF	FS	ャ	シ	フ	ワ
D	CR	GS	ュ	ス	ヘ	ン
E	SO	RS	ョ	セ	ホ	°
F	SI	US	ッ	ソ	マ	°

• When SO is received first, Kana (Japanese characters) are displayed until the next SI is received.

■ JIS(8)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	NU	DL	△	0	@	P	`	p				-	タ	ミ		
1	SH	D1	!	1	A	Q	a	q			。	ア	チ	ム		
2	SX	D2	”	2	B	R	b	r			「	イ	ツ	メ		
3	EX	D3	#	3	C	S	c	s			」	ウ	テ	モ		
4	ET	D4	\$	4	D	T	d	t			、	エ	ト	ヤ		
5	EQ	NK	%	5	E	U	e	u			・	オ	ナ	ユ		
6	AK	SY	&	6	F	V	f	v			ヲ	カ	ニ	ヨ		
7	BL	EB	’	7	G	W	g	w			ア	キ	ヌ	ラ		
8	BS	CN	(8	H	X	h	x			イ	ク	ネ	リ		
9	HT	EM)	9	I	Y	i	y			ウ	ケ	ノ	ル		
A	LF	SB	*	:	J	Z	j	z			エ	コ	ハ	レ		
B	VT	EC	+	;	K	[k	{			オ	サ	ヒ	ロ		
C	FF	FS	,	<	L	¥	l				ヤ	シ	フ	ワ		
D	CR	GS	-	=	M]	m	}			ユ	ス	ヘ	ン		
E	SO	RS	.	>	N	^	n	~			ヨ	セ	ホ	°		
F	SI	US	/	?	O	_	o	DT			ツ	ソ	マ			

■ EBCDIK

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	NU	DL	DS		△	&	-			ソ			{	}	\	0
1	SH	D1	SS				/		ア	タ	~		A	J		1
2	SX	D2	FS	SY					イ	チ	へ		B	K	S	2
3	EX	D3	WS	IR					ウ	ツ	ホ		C	L	T	3
4	PF	RE	BP	PN					エ	テ	マ		D	M	U	4
5	HT	NL	LF	TN					オ	ト	ミ		E	N	V	5
6	LC	BS	EB	NS					カ	ナ	ム		F	O	W	6
7	DT	PC	EC	ET					キ	ニ	メ		G	P	X	7
8	GE	CN	SA	S2					ク	ヌ	モ		H	Q	Y	8
9	SI	EM	SE	IT					ケ	ネ	ヤ		I	R	Z	9
A	RT	US	SM	RF	¢	!		:	コ	ノ	ユ	レ				
B	VT	C1	CP	C3	.	¥	,	#					ロ			
C	FF	IF	MA	D4	<	*	%	@	サ		ヨ	ワ				
D	CR	IG	EQ	NK	()	_	’	シ	ハ	ラ	ン				
E	SO	RS	AK		+	;	>	=	ス	ヒ	リ	°				
F	SI	IB	BL	SB		~	?	”	セ	フ	ル	°				

■ Baudot

SHIFT IN

	0	1
0	NU	T
1	E	Z
2	LF	L
3	A	W
4	Δ	H
5	S	Y
6	I	P
7	U	Q
8	CR	O
9	D	B
A	R	G
B	J	SO
C	N	M
D	F	X
E	C	V
F	K	SI

SHIFT OUT

	0	1
0	NU	5
1	3	”
2	LF)
3	-	2
4	Δ	#
5	'	6
6	8	0
7	7	1
8	CR	9
9	\$?
A	4	&
B	BL	SO
C	,	.
D	!	/
E	:	;
F	(SI

■ EBCD

SHIFT IN

	0	1	2	3
0	Δ	2	1	3
1	-	k	j	l
2	@	s	/	t
3	&	b	a	c
4	8	0	9	#
5	q	VT	r	\$
6	y	FF	z	,
7	h		i	.
8	4	6	5	7
9	m	o	n	p
A	u	w	v	x
B	d	f	e	g
C		SO	RS	ET
D		BS	CR	SY
E		EB	LF	EC
F		SI	HT	DT

SHIFT OUT

	0	1	2	3
0	Δ	<	=	;
1	_	K	J	L
2		S	?	T
3	+	B	A	C
4	*)	(”
5	Q	VT	R	!
6	Y	FF	Z	,
7	H		I	.
8	:	,	%	>
9	M	O	N	P
A	U	W	V	X
B	D	F	E	G
C		SO	RS	ET
D		BS	CR	SY
E		EB	LF	EC
F		SI	HT	DT

■ Transcode

	0	1	2	3
0	SH	&	_	0
1	A	J	/	1
2	B	K	S	2
3	C	L	T	3
4	D	M	U	4
5	E	N	V	5
6	F	O	W	6
7	G	P	X	7
8	H	Q	Y	8
9	I	R	Z	9
A	SX	△	EC	SY
B	.	\$,	#
C	<	*	%	@
D	BL	US	EQ	NK
E	SB	ET	EX	EM
F	EB	DL	HT	DT

■ IPARS

	0	1	2	3
0			@	\$
1	1	/	J	A
2	2	S	K	B
3	3	T	L	C
4	4	U	M	D
5	5	V	N	E
6	6	W	O	F
7	7	X	P	G
8	8	Y	Q	H
9	9	Z	R	I
A	0	-	:	?
B	*	#	<	.
C	CR	△	+	%
D	EI	EC	EU	EP
E	=	[)	S2
F		,	(S1

9.4 Specifications of Translation Display


BSC Translation Display

Only the control characters used in the BSC communication are displayed.

Transmission control character	Display	EBCDIC (EBCDIK)	ASCII (JIS)	Transcode
SOH	SH	01	01	00
STX	SX	02	02	0A
ETB	EB	26	17	0F
ETX	EX	03	03	2E
EOT	ET	37	04	1E
ENQ	EQ	2D	05	2D
ACK0	^A K0	10 70	10 30	1F 20
ACK1	^A K1	10 61	10 31	1F 23
NAK	^N K	3D	15	3D
DLE	^D L	10	10	1F
ITB	^I B(US)	1F	1F	1D
WACK	WAK	10 6B	10 3B	1F 26
RVI	RV	10 7C	10 3C	1F 32
TTD	TD	02 2D	02 05	0A 2D
ACK	^A K	2E	06	-

-  A character next to DLE is always displayed unconditionally.
-  The character string between STX and ETB or ETX is omitted and displayed as “-”. While the control codes between them are also not displayed, only ITB is displayed together with the result of the BCC calculation.
-  The results of the BCC calculation are displayed when the text is completed.

■ PPP frame constitution



■ Translation screen



Protocol value (h)	Mnemonic	Name
0001	Padding	Padding Protocol
0021	IP	Internet Protocol
0023	OSI	OSI Network Layer
0025	XNS	Xerox NS IDP
0027	DECnet	DECnet Phase IV
0029	AT	AppleTalk
002b	IPX	Novell IPX
002d	VJCTCPIP	Van Jacobson Compressed TCP/IP
002f	VJUTCPIP	Van Jacobson Uncompressed TCP/IP
0031	BPDU	Bridging PDU
0033	ST	Stream Protocol (TS-II)
0035	VINES	Banyan Vines
0039	AT-EDDP	AppleTalk EDDP
003b	AT-SB	AppleTalk SmartBuffered
003d	MP	Multi-Link
003f	NETBIOS	NETBIOS Framing
0041	Cisco	Cisco Systems
0043	Ascom	Ascom Timeplex
0045	LBLB	Fujitsu Link Backup and Load Balancing
0047	DCA	DCA Remote Lan
0049	SDTP	Serial Data Transport Protocol (PPP-SDTP)
004b	SNA802.2	SNA over 802.2
004d	SNA	SNA
004f	IPv6	IPv6 Header Compression
006f	SB	Stampede Bridging
00fb	CSLMG	Compression on single link in multilink group
00fd	1stComp	1st choice compression
0201	802.1dHP	802.1d Hello Packet
0203	SR-BPDU	IBM Source Routing BPDU
0205	DECLBST	Dec LANBridge 100 Spanning Tree
0231	Luxcom	Luxcom

Protocol value (h)	Mnemonic	Name
233	SigmaNS	Sigma Network Systems
8021	IPCP	Internet Protocol Control Protocol
8023	OSINLCP	OSI Network Layer Control Protocol
8025	XNSCP	Xerox NS IDP Control Protocol
8027	DNCP	DECnet Phase IV Control Protocol
8029	ATCP	Apple Talk Control Protocol
802b	IPXCP	Novell IPX Control Protocol
8031	BCP	Bridging NCP
8035	BVCP	Banyan Vines Control Protocol
803d	MPCP	Multi-Link Control Protocol
803f	NETBIOSC	NETBIOS Framing Control Protocol
8041	CiscoCP	Cisco Systems Control Protocol
8043	AscomCP	Ascom Timeplex
8045	LBLBCP	Fujitsu LBLB Control Protocol
8047	DCA-CP	DCA Remote Lan Network Control Protocol
8049	SDCP	Serial Data Control Protocol (PPP-SDCP)
804b	SNA802CP	SNA over 802.2 Control Protocol
804d	SNACP	SNA Control Protocol
804f	IPv6CP	IPv6 Header Compression Protocol
806f	SBCP	Stampede Bridging Control Protocol
80fb	CSLMGCP	compression on single link in multilink group control
80fd	CCP	Compression Control Protocol
c021	LCP	Link Control Protocol
c023	PAP	Password Authentication Protocol
c025	LQR	Link Quality Report
c027	SPAP	Shiva Password Authentication Protocol
c029	CBCP	CallBack Control Protocol (CBCP)
c223	CHAP	Challenge Handshake Authentication Protocol
c26f	SBAP	Stampede Bridging Authorization Protocol
c281	PropAP	Proprietary Authentication Protocol
c481	PropNIDA	Proprietary Node ID Authentication Protocol

Chapter 10 Specifications and Maintenance

10.1 Specifications of Function and Hardware

Interface		RS-232C (V.24) , RS-422/485, TTL
Expansion Interface ^(*)		Current Loop[OP-SBIC]
Standard Protocol		Asynchronous , Asynchronous PPP
Capture Memory	Memory capacity ^(*)	32MB
Transmission speed	Max speed in full-duplex	500Kbps
	Max speed in half-duplex	500Kbps
	Speed setting range	50bps - 500Kbps
	Setting step	Freely set to four effective digits, separately for transmission and reception. (Margin of error: +/- 0.01% or less)
Data format		NRZ
Data code		ASCII, EBCDIC, JIS7, JIS8, Baudot, Transcode, IPARS, EBCD, EBCDIK, HEX
Parity bit		NONE,ODD,EVEN,MARK,SPACE
Bit sequence		LSB First, MSB First
Polarity		NORMAL, INVERTED
Error check function		Parity(ODD,EVEN,MARK,SPACE),Flaming, Break, BCC (LRC,CRC-6,CRC-12,CRC-16,CRC-ITU-T,FCS-16,FCS-32)
Online monitor function	Specification	Communication log is recorded continuously and displayed in the LCD without affecting the communication lines.
	Idle time record	100m sec, 10m sec, 1m sec, OFF (no record) are selectable.MAX 999.9sec
	Time stamp record	[Year Month Day Hour Min],[Month Day Hour Min Sec][Day Hour Min Sec 10m sec],OFF(no record) are selectable.
	Line status record	Records and displays the wave form of 4 signals which chosen from RS, CS, ER, DR, CD, CI, EXIN along with the transmission reception data.
	Data display controll	Temporary Stop, Scroll, Paging, Jump
Protocol		PPP, BSC
Timer/Counter	Interval Timer	2 Type MAX count 999999 (1m sec,10 msec and 100msec are selectable.)
	General purpose counter	2 Type MAX 999999
	Transmission/ reception data counter	For SD/RD 1 for each. Max count 4294967295
Trigger function	Specification	Up to 4 pairs of trigger condition and action can be specified.(sequential action, which validates another condition after one condition satisfied, is also possible.)
	Trigger condition	Communication error, communication data string up to 8 characters, idle time more than the specified duration, match time/counter value, logic status of interface signal line and external trigger input.
	Trigger Action	Stops measurement/test(offset can be set), validates trigger condition: controls timer, controls counter, activates buzzer, saves monitor data on a memory card, sends the specified character string, sends pulse to external signal.
Search function	Specification	Retrives the data with specific condition from capture memory.
	Search Condition	Communication error, communication data string up to 8 characters, idle time more than the specified duration, specified timestamp(don't care available) trigger matching data.
Monitor conditions auto setting		Measurement conditions such as protocol, transmission speed,(max 115.2Kbps), data code.
Auto run/stop function		Enables measurement to start and end at the specified time at the selected repeating cycle(monthly, daily, hourly ^(*))
Power on auto run function		Measurement starts automatically after power on the analyzer.

Auto save function	Specification	Automatically saves the monitored data in the capture memory and saves as communications log file in the storage device.
	File size	BUF(capture memory size), 1MB,2MB,4MB,8MB,16MB,32MB
	Max file size	1024
Delay time mesurement function		Measure the delay time between one condition of the interface signal and the another.
Signal voltage measureing function		Measures and displays the value of voltage amplitude:SD,RD,ER,CD of RS-232C.
Logic analyzer function	Specification	Measures the logical change of the interface signal in the sampling clock period, and displays its wave.
	Sampling clock	1KHz -20MHz (14steps) (Min : 2Ksamplings)
	Zoom in/out	x6-x1/64 (11steps)
	Other Function	Function which calculate the time between two points. Replacement of signal line function. Search the signal status function.
Simulation function	Action specification	Enables transmission/ reception test of any given data in DTE or DCE mode(selectable with pin arrangements).
	MANUAL	Sends the data assinged to peration keys each time a key is pressed, while checking communications status on the display.
	FLOW	Simulates the X-on/Xoff control data and flow control procedures of RTS/CTS control line.
	ECHO	Send the received data frame(buffer echo) by frame,by data(character echo) or by loop back.
Bit error rate test		Measure error rate conforming to ITU-T Notifiatiion G.821 parameter and Loop back test..
File management function		Measurement data and condition can be saved in the SD card. AND the format of the data /condition can be used in the PC.
SD card interface Max. card capacity ^(*4)		16GB
Wi-Fi interface ^(*5)		IEEE802.11b/g/n Frequency range : 2400MHz-2483.5MHz TX POWER: 802.11b : +20dBm 802.11g : +17dBm 802.11n : +14dBm
LCD display		Monochrome 240×64 dot with Back-light
AUX (RS-232C) port		Mini DIN 8pin connnector Communication Speed : 9600bps ~ 230.4Kbps (6 steps)
USB2.0 device Port		Support High speed transmission in Device B connector for PC connection
USB2.0 host port		Support High speed transmission in Device A connector for USB flash.
AC adapter		Attached AC adapter, Input : AC100 - 240V, 50/60Hz
Built-in secondary battery		Nickel metal hydride (Model : P-19S) Battery charging time : About 2.5H Battery operation time : About 6.5 ~ 8H ^(*6)
Temprature, Humidity		In operation : 0 - 40 °C In storage : -10 - 50°C under 85%RH
Regulatory Approvals		CE (class A)
Dimensions (W×D×H)		210(W)×154(D)×38(H) mm
Weight		Approx. 760g

*1: To use the function, the optional accessories described in the brackets are required.

*2: Transmission/reception data, idle time, time stamp, and line status items consume 4 bytes of memory at each capture.

*3: If the amount of communication data is small or communication data includes several errors, a proper auto setting cannot be done.

*4: Operation is not guaranteed with SD cards not specified by LINEEYE when using.

*5: Wi-Fi function is available only in Japan, USA, Canada, and EU nations where the product is needed to be compliant with RE directive (2014/53/EU). The Wi-Fi function of this product is set to invalid depending on the country where it is shipped. Pleasecontact LINEEYE for the detail.

*6: The battery operating time was measured under LINEEYE's measurement conditions.


10.2 Ports

RS-422/485 port

This port is used for measuring and testing RS-422/485. Input/output specifications of each signal can be changed by setting monitor (MONITOR), simulation DTE (SIM-DTE), and simulation DCE (SIM-DCE).

- Signal definition of RS-422/485 port

 2.2 Set the Measurement Port ((INTERFACE SETUP)



Signal	Terminal	Input/Output(*1)			Linestate LED
		Monitor	SIM-DTE	SIM-DCE	
Transmission data	TXD-	I	O	I	SD[A]:-
	TXD+	I	O	I	SD[B]:+
Receiving data	RXD-	I	I	O	RD[A]:-
	RXD+	I	I	O	RD[B]:+
Signal Ground	GND	-	-	-	RS[A]:-


*1: "I" is an input to the analyzer. "O" is an output from the analyzer.

TTL Port

TTL (UART) port for measurement and test

- TTL (UART) signal definition

 2.2 Set the Measurement Port



Connector: 2.54mm pitch
Pin header type

Signal	Pin name	Input/Output(*1)		Linestate LED
		MONITOR	SIMULATION	
Transmission data	TXD-	I	O	SD
Receiving data	RXD-	I	I	RD
RTS	RTS	I	O	RS
CTS	CTS	I	I	CS
Signal Ground	GND	-	-	

*1: "I" is an input to the analyzer. "O" is an output from the analyzer


RS-232C (V.24) port

This port is used for measuring and testing RS-232C. The standard pin arrangement is used on the specification of V.24.

Input/Output specifications of each signal can be changed by setting monitor (MONITOR), simulation DTE (SIM-DTE), and simulation DCE (SIM-DCE).

 2.2 Set the Measurement Port

■ Signal definition of RS-232C




Signal name	RS-232C(V.24)		Signal Input / Output (*3)			LineState LED	LineState LED (JIS standard)
	DSUB25	Pin(*2)	MONITOR	DTE	DCE		
Shield ground	FG	1	-	-	-		
Signal ground	SG	7	-	-	-		
Transmission data	SD	2	I	O	I	SD	SD
Receiving data	RD	3	I	I	O	RD	RD
Request of transmission	RTS	4	I	O	I	RTS	RS
Capable of transmission	CTS	5	I	I	O	CTS	CS
Terminal ready	DTR	20	I	O	I	DTR	ER
Data set ready	DSR	6	I	I	O	DSR	DR
Data carrier detect	DCD	8	I	I	O	DCD	CD
Call indicator	CI (*1)	22	I	I	-	RI	CI
Transmission timing DTE	ST1	24	I	O	I	TXC1	ST1
Transmission timing DCE	ST2	15	I	I	O	TXC2	ST2
Receive timing DCE	RT	17	I	I	O	RXC	RT

*1: CI signal cannot be outputted from this analyzer.

*2: The pins not mentioned are for non-connection.

*3: "I" is an input to the analyzer. "O" is an output from the analyzer.

External Input/Output Terminal



Connector: 2.54mm pitch
pin header type

Signal name	Pin name	Input/Output
Power for external circuit(*1)	PWR	
External trigger output 2 (TTL level output)(*2)	OT2	O
External trigger output 1 (TTL level output)(*2)	OT1	O
External trigger input (TTL level input)(*3)	IN	I
Signal GND	GND	-

*1: Voltage () can be set in "LEVEL" item.
Maximum output current is 30mA.


 2.2 Set the Measurement Port

*2: Open drain output, +5V, 10KΩ pullup

*3: Input voltage range is -0.5V - 6.0V. It is pulled up with 10KΩ on +5V.

The dedicated port to communicate with external devices equipped with RS-232C interface.

Pin number	Signal name	I/O	Description
1	Empty terminal		
2	SG	-	Signal ground
3	AUX CS	I	Set to "Low" level to inhibit data output from the analyzer.
4	AUX RD	I	Receives data from an external device.
5	AUX RS	O	Remains on 'High' level when the analyzer is ready for data input.
6	AUX ER1	O	Remains on 'High' level while the power of the analyzer is ON.
7	AUX SD	O	Outputs data to external device.
8	AUX ER2	O	Remains on 'High' level while the power of the analyzer is ON.




Connector : Mini DIN 8pin connector (female)
TCS7588-01-201(Hosiden Corporation) or the like

Optional AUX cable "LE2-8V"

The analyzer (AUX port)		External device (RS-232C)	
Mini DIN connector		DSUB connector	
Pin number	Pin number	Pin number	Name
1	—————	4	DTR
2	—————	5	GND
3	—————	7	RTS
4	—————	3	SD
5	—————	8	CTS
6	—————	1	DCD
7	—————	2	RD
8	—————	6	DSR
Metal shell	—————	Metal shell	

USB Device port

USB device port is used to communicate a PC via USB2.0 port.




Connector specification: Type B (Female)

Pin No.	Signal	Description
1	VCC	+5 VDC
2	D-	data -
3	D+	data +
4	GND	signal ground

USB Host port

USB host port is used to connect USB flash.



Connector specification: Type A (Female)

Pin No.	Signal	Description
1	VCC	+5 VDC
2	D-	data -
3	D+	data +
4	GND	signal ground

USB Driver Installation

USB port is used to update the latest firmware via PC or use an optional PC software.

You need to install a driver in the PC.

 Supported OS are Windows 7/8/8.1/10.

<Installation>


●Windows 7

1.Set the attached CD-ROM into the CD-ROM drive of the PC.

2.Execute "setup.exe" file in "Driver" folder of the attached CD-ROM.

3."User Account Control" appers in the display of the PC.

Then click "Yes".




4."LINEEYE driver package installer" appears. Then click "Yes".

5."Device Driver Installation Wizard" appears. Then click "Next".

6.Windows security window appears.


Then click "Install".



7.If the window says "Completing the Device Driver Installation Wizard", click "Finish".

8.Connect the analyzer to the PC. The installation is completed if the message like below is appears on the task tray.

 Above is the installation for Windows 7. It will be almost same for Windows Vista/8.



10.3 Soft Reset

Soft reset means restoring the analyzer to the initial conditions at the time of delivery. (factory setting)

Turn on the power switch, while pressing [ENTER]+[TOP/DEL] keys. [INITIALIZED!] will be displayed in the opening screen.



- ☞ Soft reset clears all data, including the monitor data in the buffer.

10.4 Using the Latest Function

The new function addition and the improved latest firmware are published on our web page.

After you download to your PC, it is easy to rewrite up to date via attached AUX cable.

- ☞ To learn more about detailed method to rewrite, please refer to LE8FIRM.TXT recorded in the Utility folder of attached CD.

10.5 Troubleshooting

- This section describes how to solve problems when the analyzer does not operate normally.

Problem	Cause / Remedy
Cannot turn on the power	<ul style="list-style-type: none"> • Charge the battery. • The battery reached its life span. • The product is breakdown if BT LED is not blinking green while connecting the AC adaptor.
Battery cannot be recharged	<ul style="list-style-type: none"> • If BT LED is not lighting, supply the power (AC adaptor). • If BT LED is blinking fast, the product is breakdown or disconnection. • Recharge under the temperature of 5-40°C. • The battery reached its life span.
Cannot display any	<ul style="list-style-type: none"> • Adjust the contrast. • Use the product under the temperature of 0-40°C.
Cannot use the backlight	<ul style="list-style-type: none"> • Press [MENU]->[3]->[6] and select "BL OFF" to other than "0". "0" is for the automatic backlight off for saving power.
Display <Firmware loader>	<ul style="list-style-type: none"> • Insert the sub-board. • Load the necessary firmware in the analyzer.
Disappear measured data	<ul style="list-style-type: none"> • If you press [RUN], previous measured data will be erased. • Built-in battery reached its life span. Please ask LINEEYE to replace it.
Date or time is not displayed correctly.	<ul style="list-style-type: none"> • Display DATE/TIME on the condition menu and set the correct date and time. • Built-in battery reached its life span if date becomes incorrect often.
Cannot operate any keys	<ul style="list-style-type: none"> • Cannot operate any keys while accessing to the SD card. • Cannot operate any keys while using the PC link software (LE-PC300R). • Remove all cables. Key operation become extremely slow when high speed data is measured.
Cannot work well A part of display is not correct	<ul style="list-style-type: none"> • Turn off the power and then turn on the power again. • Reset the software (turn on the power while pressing [ENTER]+[TOP/DEL]). It will go back to the factory setting and erase all data.
Line state LED does not light	<ul style="list-style-type: none"> • Connect the cable properly • Make sure a port you connect cable is same in the setting ([Menu]->[1]->[PORT]). • Check the cable snapping or disconnection.
Line State LED lights but cannot monitor or display anything	<ul style="list-style-type: none"> • Select "On Line" monitor function. • Press [MENU]->[0] and set appropriate conditions. Check speed
Line State LED lights but cannot monitor and display errors	<ul style="list-style-type: none"> • Select "On Line" monitor function. • Press [MENU]->[0] and set appropriate conditions. Check speed, data length, parity bit, FCS and BCC etc.
Errors occur in the target device when pressing [RUN]	<ul style="list-style-type: none"> • Select "On Line" monitor function. Output signals collide if selecting Simulation.
Cannot output data in Simulation or BERT	<ul style="list-style-type: none"> • Select "Simulation" or "BERT" function. • Press [MENU]->[1] and select appropriate interface. • Press [MENU]->[0] and set appropriate conditions.
Cannot set appropriate conditions by Auto Configuration	<ul style="list-style-type: none"> • Cannot use if the speed of target device is over 115.2Kbps. • Auto Configuration many not be correct because the communication condition of targe device varies.
Cannot use SD card	<ul style="list-style-type: none"> • Use the SD cards which LINEEYE guarantees to use. • Each model of analyzer has max capacity of using the SD card. • Format the SD card by the analyzer.
Cannot use Wi-Fi	<ul style="list-style-type: none"> • The Wi-Fi function is available only in Japan, USA, Canada, and EU nations where the product is needed to be compliant with RE directive (2014/53/EU). • Confirm your region. • Confirm the setting of SSID and KEY of Wi-Fi. • <u>Move the analyzer to where gives good reception.</u>
Unable to printout	<ul style="list-style-type: none"> • Select "OUTPUT" to "AUX" from [MENU]->[3]->[2]. • Select the serial port for DPU-414 printer.
Cannot connect to a PC via USB port	<ul style="list-style-type: none"> • Install the USB driver in the PC. • Check if the security software interrupt the connection.

10.6 Warranty and After service



Warranty

- When you face any problems, please contact LINEEYE distributors or LINEEYE.
- **Warranty**
Within a period of 12 months from the date of shipment, LINEEYE warrants that your purchased products (except consumable parts such as the battery and software) are free of charge from any defects in material and workmanship, only when the products are operated in accordance with procedures described in the documents supplied by LINEEYE. If the defects exist during the Warranty period, please send back the products to LINEEYE distributors or LINEEYE. LINEEYE will repair or exchange them at no charge. In this case, the shipping charge will be at your own expense.
The foregoing warranties are the sole warranties given by LINEEYE. Above warranties shall not be applied to the products that have been modified, repaired or altered (except by LINEEYE) or that have been subjected to unusual physical or electrical stress, misuses, abuse, negligence or accidents.
LINEEYE disclaims all other warranties including the warranties of merchantability fitness for some particular purpose and noninfringement of third party right. LINEEYE cannot promise that the software is error-free or will operate without any interruption.



User Registration

For after service and other information, please register in our Website.



Repair

For malfunction, please contact LINEEYE distributors or LINEEYE and tell us following details.

Model	LE-1500R
Serial Number	8 digit numbers
Purchase Date	Year, Month, Day
Other	Details of malfunction



10.5 Troubleshooting

- **Repair within the warranty**
LINEEYE repairs, following the repair instruction.
Please provide the details of malfunction.
- **Repair after the warranty**
LINEEYE will repair the products at our own expense.
- **Calibration**
Enable to have a hardware calibration test by the analyzer
 1. Remove all cables from the analyzer and save the important data.
 2. Turn on the power while pressing [I] + [D].
 3. Follow the instruction in the screen.
 4. "===== O K =====" will be displayed if the result is fine.



After Support

Read "FAQ" in our Website or email us.

Please refer to "FAQ". We also have support by email regarding the technical issue. When you use it, please register your product via our website.

Website: <https://www.lineeye.com>

Email: info@lineeye.co.jp

LINEEYE CO., LTD.

4F., Marufuku Bldg., 39-1, Karahashi Nishihiragaki-cho, Minami-ku,
Kyoto, 601-8468, Japan

Tel : 075(693)0161 Fax : 075(693)0163

URL <https://www.lineeye.com> Email :info@lineeye.co.jp

Printed in Japan